


Instruction Manual

Marble Rush[™] Corkscrew Challenge



Item No.: 80-519403

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



Interactive toys to develop their imagination and encourage language development

l want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

l need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

```
4-10 years
```

To learn more about this and other VTech® products, visit www.vtech.co.uk

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

l am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months

INTRODUCTION

Thank you for purchasing the **Marble Rush™ Corkscrew Challenge!** Get ready for a rush of non-stop action! Build thrilling courses, send the marbles into motion and compete with family and friends through exciting challenges complete with sounds and lights.

INCLUDED IN THIS PACKAGE

- Marble Rush[™] Corkscrew Challenge
- 102 Components & 10 Marbles
- Quick Start Guide
- Colour Manual

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE: Please save this Instruction Manual as it contains important information.

WARNING:

Do not aim at eyes or face.

WARNING:

Do not discharge any object other than the marbles provided with this toy.


WARNING:

CHOKING HAZARD -Toy contains small parts and small balls. Not for children under 3yrs.

GETTING STARTED

Battery Removal and Installation

- Make sure the Marble Rush™ Corkscrew Challenge is turned Off.
- 2. Find the battery cover located on the back of the unit, use a coin or screwdriver to loosen the screw and then open the battery cover.



- 3. Remove old batteries by pulling up on one end of each battery.
- Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
- 5. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Australia/New Zealand:

If you think batteries might have been swallowed or placed inside any part of the body, immediately call the 24-hour Poisons Information Centre on 13 11 26 (in Australia) or 24-hour National Poisons Centre on 0800 764 766 (in New Zealand) for fast, expert advice and go straight to the nearest hospital emergency room.

Disposal of batteries and product

The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech[®] cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you. In Australia & New Zealand:

Check with your local council for kerbside collections.

LABEL APPLICATION

Please securely stick the labels to the play set as indicated below:











T-15







T-17

T-04

M-04

M-05



M-16



T-02



B-02



B-04



T-03



```
T-01
```

PRODUCT FEATURES


1. Corkscrew Tumbler

When a marble passes through the **Corkscrew Tumbler**, lights will flash and the unit will play sound effects.




2. Corkscrew Tumbler Button

Press this button to change the music.



3. Off/Sound Switch

Slide the switch to the right ((J)) to turn on both music and sound effects. Slide the switch to the middle position J_{0} to play only sound effects. Slide the switch to the left \blacksquare to turn the unit off.



4. Automatic Shut-Off

To preserve battery life, the **Marble Rush™ Corkscrew Challenge** will automatically turn off after several minutes without input. The unit can be turned on again by sliding the **Off/Sound Switch** to a Sound position. The unit will also automatically turn off when the batteries are very low. If the unit powers down while playing, install a new set of batteries.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries if the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
- 5. If the unit is not working properly, install a brand new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK) Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155 Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785 Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/ consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au



TM & © 2022 VTech Holdings Limited. All rights reserved. IM-519400-000 Version:0