
BM4400



Safe & Sound Colour Video & Audio Baby Monitor






on purchasing your new VTech product. Before using this product, please read **Important** safety instructions.

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please installation and operation of this innovative and feature rich VTech product.

### What's in the box











# User's manual

Press to play or stop lullabies on the

is ON when the baby unit is turned

on and is paired to the parent unit.

Flashes when the baby unit is not

Press to play the next lullaby.

being viewed; or when the link to the

Press to adjust the speaker volume.

talkback volume transmitted from

Slide to turn the baby unit on or off.

For wall mount installation use

Your baby unit and parent unit

provided are already paired.

It determines the lullaby volume and

Light sensor

Infrared LEDs

▶/■ Play/Stop

**ON/OFF light** 

Microphone

parent unit.

Temperature sensor

Threaded socket

也 switch

Speaker

Power jack

**▶** Skip

parent unit is lost.

Camera

## **Congratulations**

review this manual thoroughly to ensure proper












## Install the battery


You can power up the parent unit by connecting it to AC power or to the rechargeable battery provided. Even if the parent unit is connected to AC power, we recommend you also install the battery. This guarantees continual operation in case of a power outage.

Install the battery as shown below.




#### **Ø**NOTE

· Press down on the large tab of the battery compartment cover to pull it out.



. Make sure the label THIS SIDE UP is facing up while inserting the battery.



#### Replace the battery

To replace the battery, press down on the large tab of the battery compartment cover and pull it out, then follow the steps above to install the battery.

#### **O**NOTES


- · The operating time for using the rechargeable battery is short. If you want to monitor your baby for a long time, we recommend you connect the parent unit to AC power
- If the parent unit will not be used for a long time. disconnect and remove the battery to prevent possible leakage

## Connect and charge the battery

#### **Ø**NOTES

- · Use only the battery supplied with this product.
- Use only the power adaptors supplied with this product.
- · Make sure the electrical outlets are not controlled by wall switches.
- The power adaptors are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if they are plugged into a ceiling, under-the-table or cabinet outlet
- Make sure the parent unit, the baby unit and the power adaptor cords are out of reach of children.

## Connect the baby monitor



## Charge the parent unit battery

When you have connected the parent unit and installed its battery for the first time or after a power outage, the parent unit will power on automatically. The battery icon indicates the battery status (see the following table).

#### **Ø**NOTES

Battery

- The parent unit battery is fully charged after 3 hours of continuous charging
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging.

Battery

 The standby time varies depending on the sensitivity level you set, your actual use and the age of the battery.

Action

indicators	status	
The battery icon is off and had displays.	No battery is installed but operates using AC power, or the battery has been installed incorrectly.	Install the parent unit battery. Charge without interruption (at least 30 minutes).
The screen displays  Battery low at Parent Unit and The Ight flashes.	The battery has very little charge and may be used for only a short time.	Charge without interruption (about 30 minutes).
The battery icon becomes solid	The battery is fully charged.	To keep the battery charged, connect it to AC power when not in use.

## Before use

Test your baby monitor

use, and at regular times thereafter.

> 1m (3ft)

You should test the baby monitor before initial

• For hearing protection, make sure the parent unit

is more than 1 metre (3 feet) away from the baby

unit. If you hear any high-pitched noise, move the

parent unit further away until the noise stops. You

can also press -/VOL on the parent unit to lower or

1. Make sure your baby unit and parent unit

2. The parent unit displays images from the

· Increase the parent unit speaker volume if you cannot hear the sounds transmitted from the baby

Speak towards the baby unit microphone.

You will hear the sound at the parent

not be used as such.

mute the noise

baby unit

· This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should

**Ø**NOTE To avoid interference from other electronic devices, place your baby monitor far away from devices such as wireless routers, microwaves, mobile phones and computers.


baby's cot or playpen.

Positioning the baby monitor

Keep the baby unit out of the reach of your baby.

Never place or mount the baby unit inside the

1. Place the baby unit more than 1 metre (3 feet) away from your baby.




2. Adjust the angle of the baby unit camera to aim at your baby.



3. Place the parent unit more than 1 metre (3 feet) away from the baby unit.





## **D**CAUTION

- The default volume of your parent unit is level 4. If you experience high-pitched screeching noise from your baby monitor while positioning:
- more than 1 metre (3 feet) apart, OR

#### - Make sure your baby unit and parent unit are

- Turn down the volume of your parent unit.


# Operating range


The operating range of the baby monitor is up to 300 metres (1,000 feet) outdoors or 50 metres (160 feet) indoors. The actual operating range may vary depending on the environmental conditions and other interferences such as walls, doors and other obstructions.

#### Overview


## Baby unit overview







# Parent unit overview



1	Speaker
2	Power jack
3	Stand
4	Antenna
5	LED lights
	Indicate the different statuses of the parent unit. For details, refer to Parent unit lights.
6	Microphone
7	ம் On/off
	Press to power on.

	(1)
6 - 7 - 8 - 9 - 0 - 11 -	(5) (13) (14) (15) (15) (16) (17) (17) (17) (17) (17) (17) (17) (17
1	Speaker
2	Power jack
3	Stand
4	Antenna
5	Indicate the different statuses of the parent unit. For details, refer to Parent unit lights.
6	Microphone
7	<ul> <li>On/off</li> <li>Press to power on.</li> <li>Press and hold to power off.</li> </ul>
8	(1) <sup>4</sup> 2
	Whilst viewing an image, press and hold to talk to the baby unit.
9	⊕ Zoom
	Whilst viewing an image, press to zoom in or out.

# Whilst in a menu, press to select a

- Whilst viewing an image, press and hold to move the image to the right.
- Whilst in a menu, press to return to
- the main menu or idle screen. Whilst viewing an image,
- press and hold to move the image to the left.
- Press and hold to turn the parent unit screen off.
- Press to skip to the next lullaby.
- Press to play or stop the lullaby.
- Press to increase the speaker
- Press to decrease the speaker volume.
- 15 |<del>♦</del>/OK Press to enter the menu.

16

- Whilst in a menu, press to choose an item or save a setting.
- Whilst in a menu, press to scroll up. Whilst viewing an image, press and hold to move the image
- Whilst in a menu, press to scroll down.

upwards.

Whilst viewing an image, press and hold to move the image

## Parent unit lights

On when moderate or high signal strength is detected between the parent unit and the baby unit. Flashes when low signal strength is detected between the parent unit and the baby unit. Off when the parent unit is turned

off, or the link to the baby unit is On when the parent unit is connected to AC power, or the

battery is charging. Flashes when the parent unit battery is low and needs charging. Off when the parent unit is disconnected from AC power.

On when the parent unit is talking to the baby unit. On when the parent unit speaker volume is turned off.

#### Parent unit display icons



# Connection status

displays when strong signal strength is detected between the baby unit and the parent unit.

- or displays when moderate or low signal strength is detected between the baby unit and the parent unit.
- T displays when the link between the baby unit and the parent unit Night vision
- Displays when the baby unit has activated the night vision feature. Displays when the baby unit
- Temperature alert tone Displays when the temperature alert tone is set on.

camera has zoomed in.

## Real-time temperature

Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. **57** °F or **14** °C).

# Mute alert

### Displays when the parent unit speaker volume is set to off.

#### 9-level sound indicator (1 to 3 bars) indicates low

sound level detected by the baby (4 to 6 bars) indicates

moderate sound level detected by the baby unit. (7 to 9 bars) indicates high

sound level detected by the baby unit (e.g. baby crying loudly). Speaker volume

## Displays the parent unit speaker volume level while adjusting.

**Battery status** animates when the battery is charging.

im displays solid when the battery displays when the battery is



low and needs charging. AC power without battery Displays when the parent unit is connected to AC power without the battery.

## Parent unit main menu icons

You can select the language to be

used in all screen displays.

### **Alert Tone** You can set the parent unit to beep

Sensitivity

the parent unit operates in low battery condition;

the link between the parent unit and the baby unit is lost.

## to hear sounds from the baby unit all the time, or to hear sounds that

to the parent unit.

temperature range.

Vibration

exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting

With this feature, you can choose



You can turn on the **Temperature** alert tone so that the parent unit beeps whenever the room temperature detected by the baby unit falls outside of the desired



You can turn on the vibration alert so that the parent unit vibrates when it receives Low battery tone, No link alert, Sound alert or Temperature alert tone after turning on the respective alert tones. Lullaby



You can choose the lullabies to play on the baby unit to comfort your



Sound-activated Screen Automatically turns on the parent unit screen when the baby unit detects a sound after the screen is turned off. When no sound is detected, the screen is automatically off to save power.

## You can change the brightness of the parent unit screen, or turn on the **Dim Mode** to save power. You can choose a specific name for the baby unit from a pre-defined name list Pair/Unpair The baby unit and parent unit provided are already paired.

### Parent unit display messages

Battery le	w at large level of the parent unit is very low and needs to be recharged.
Battery empt Powering off	
Tempera too high at Co	detected by the baby unit is higher/lower than the desired temperature alert range.
Powering on	The parent unit is turning on.
3	The parent unit is searching for baby unit.

- Powering the baby unit on or off Slide the Φ switch upward on the baby unit
- to **ON** to power on. The power light turns on. C>TIP Slide the  $\odot$  switch downward on the baby unit

# Powering the parent unit on or off

to **OFF** to power off. The power light turns off.

- Press and hold to power on the parent unit. The screen turns on
- Press and hold Φ again to power off the parent unit. The screen turns off.

#### Turn the parent unit screen on or off

You can turn the parent unit screen on or off without turning the parent unit off. You can still hear sound from the baby unit.

- Press and hold on the top of the parent unit to turn the screen off
- Press any key on the parent unit to turn on the screen again

## Adjust the speaker volume

#### For parent unit:

- Press + or on the parent unit at any time when viewing images.
- When the parent unit speaker volume is set to zero, appears on the screen and the  $\bowtie$  light turns on.

#### For baby unit:

The baby unit speaker volume determines the lullaby volume and talkback volume transmitted from the parent unit.

• Press - /+ on the baby unit to adjust the speaker volume.

#### Play Iullabies

the power-on

baby unit and

go on when I

switch on the

Why doesn't

charge while

AC power?

black and

Why do I get

glare or blurry

display on my

baby at night?

Why does the

produce a

high-pitched

viewina mv

parent unit

units?

light of the

You can play lullabies on the baby unit to comfort your baby. There are 5 lullabies to choose from. The selected lullaby plays repeatedly for approximately 20 minutes.

## Play lullabies using baby unit control keys

- Press ►/■ on the baby unit to play lullaby. It starts playing lullaby for 10 minutes.
- Press ➤ on the baby unit to switch to the other lullabies

baby unit.

my parent unit | controlled by a wall switch

battery.

Perhaps the parent unit is not

connected to the mains. Insert

the appliance plug into the paren

unit and put the adaptor in a wal

socket. Then press and hold U

to switch on the parent unit and

to establish connection with the

connected to the mains. Connect

the baby unit to the mains. Then

set the **(b)** switch to **ON** to switch

on the baby unit and to establish

Make sure the battery is correctly

You may have used the battery

The screen is in black and white

for a long time. Replace a new

during night-time or in a dark

During night-time or in a dark

interfering factors, like lights,

room, the surroundings and other

objects, colours and background

may affect the image quality on

vour parent unit screen. Adjust

ne baby unit's angle or place

prevent glare and blurry display.

be too close to each other.

noise stops; OR

parent unit.

the baby unit at a higher level to

The parent unit and baby unit may

Move the parent unit away

from the baby unit until the

Turn down the volume of your

room. This is normal due to

external light sources.

connection with the parent unit.

Make sure the power is not

nstalled in your parent unit

Perhaps the baby unit is not

Press ►/■ again to stop the lullaby.

#### Play lullabies using parent unit control keys Press ▶/■ on the parent unit to play

Iullabies

Press \( \square\) on the parent unit to switch to the

If Play all is selected, the five lullables

play one after the other repeatedly for

2. Press ▼ or ▲ to scroll to LULLABY.

3. Press ▼ or ▲ to scroll to your desired

Press ▼ or ▲ to scroll to Play or Stop.

Press ⇒/OK to confirm your selection.

6. Press ♦/OK to confirm your selection.

Lullaby playback is paused when the parent

unit is talking to the baby unit. Lullaby playback

You can select the language to be used in all

1. Press ♦/OK when the parent unit is idle.

2. Press ▼ or ▲ to choose Language, then

You can change the brightness of the parent

1. Press ♦/OK when the parent unit is idle.

2. Press ▼ or ▲ to choose LCD, then press

Press ⇒/OK again to choose Brightness.

4. Press ▼ or ▲ to choose the desired level

of brightness, then press ♦/OK to confirm

on before pairing.

unit is idle.

Pair CAM.

The baby unit is unpaired from

the parent unit. Follow the steps

to pair the baby unit. Make sure

both parent unit and baby unit are

Pair/Unpair CAM, then press

Press ♦/OK again to choose

Press ▼ or ▲ to choose an

press ♦/OK. The parent unit

screen displays Press and

hold the pair button at the

power indicator flashes..

on the bottom of the

baby unit with a narrow

pointed object such as a

When pairing is successful, the

screen displays the view of the

newly paired baby unit. The

remains on.

less than 3 feet).

LED light on the new baby unit

If pairing fails, the screen

pairing process again.

range. Move the parent unit

If the parent unit is powered

by the provided battery, it may

not have enough charge for the

parent unit to perform normally.

Charge the battery in the parent

The temperature of your baby's

room may be too high or too low.

sensitivity level to **Highest** when

feature are turned on. The parent

including background noise with

beeps (or vibrations). Adjust the

sound sensitivity to a lower level

The baby unit also picks up other

sounds than those of your baby.

Adjust the sensitivity level to a

lower level or lower the parent

other sounds? unit speaker volume.

the sound alert (and vibration)

unit notifies you of all sounds

You may have set the sound

unit for up to 3 hours.

closer to the baby unit (but not

displays Pairing failed. Try the

Immediately press and hold

pencil. The LED light flashes

CAM for 5 seconds until the

empty baby unit slot, then

Press ▼ or ▲ to choose

unit screen from Level 1 to Level 5. The LCD

language, then press ♦/OK to confirm your

3. Press ▼ or ▲ to choose your desired

Adjust LCD brightness

brightness is preset to Level 3.

your selection.

The ON/OFF

light on the

flashes and

the parent unit displays .

Why does the

Why does the

parent unit

beep/vibrate

frequently?

Why does

the parent

quickly to

unit react too

parent unit

baby unit

resumes when the parent unit finishes using the

1. Press  $\Rightarrow$ /OK when the parent unit is idle.

approximately 20 minutes.

lullaby or Play all.

TALK feature.

screen displays.

press +>/OK

Set the language

- Press ▶/■ again to stop the lullaby.
- When the lullaby stops, press ►/■ again to replay. 3. Press ▼ or ▲ to choose **Dim Mode**, then Play lullabies using parent unit menu

  - 4. Press **▼** or **▲** to choose **On** or **Off**, then press ♦/OK to confirm your selection.

1. Press  $\Rightarrow$ /OK when the parent unit is idle.

2. Press ▼ or ▲ to choose LCD, then press

# **⊘**NOTE

• When the screen is dimmed, any key press or alert message will trigger the screen to return to the preset brightness level. After 10 minutes of idle, it will be dimmed again.

#### Adjust the sound sensitivity of the baby unit

You can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit from Lowest to Highest. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. The sound sensitivity level is preset to Highest.

#### Sound sensitivity table for reference

Sound sensitivity table for reference		
Sensitivity Level	Description	
Highest	The parent unit speaker is constantly on, and you will hear all sounds (including background noises) from your baby's room.	
High	The parent unit speaker turns on for soft babbling and louder sounds from your baby. It remains quiet when your baby sleeps soundly.	
Medium	The parent unit speaker turns on for loud babbling and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	
Low	The parent unit speaker turns on for crying and louder sounds from your baby. It remains quiet when your baby makes soft sounds.	
Lowest	The parent unit speaker turns on for loud crying or screeching sounds from your baby. It remains quiet when your baby makes soft sounds.	

hear a sound/

Why can't I

Why can't I

connection'

Why is the

lost every no

there sound

interruptions'

and then?

hear my baby

The parent unit speaker volume

+/VOL to increase the volume.

You may have set a low sound

sensitivity level. See Adjust the

sound sensitivity of the baby

(observe the minimum distance

Other electronic products may

cause interference with your bab

monitor. Try installing your baby

monitor as far away from these

electronic devices as possible

unit to set to a higher level.

The baby unit may be out of

range. Move the parent unit

closer to the baby unit

of 1 metre/3 feet).

may be too low or off. Press

#### Turn the dim mode on or off

The dim mode is preset to on to help you save the parent unit power. Whenever the parent unit has been left idle for 10 minutes while the screen is still on, the screen will be dimmed automatically to save power

sensitivity level, then press ⇒/OK to confirm your selection. CAIL 43

3. Press ▼ or ▲ to choose the desired

press -♦/OK

 You can adjust the baby unit placement to improve the sound detection

Press ⇒/OK when the parent unit is idle.

2. Press ▼ or ▲ to choose Sensitivity, then

#### Turn the sound activation on or off

When sound activation is on, as long as no sound is detected within 50 seconds, the parent unit screen will turn off automatically to save power

When your baby unit detects a sound, the sound activation triggers the parent unit screen to turn on automatically. When no sound is detected within 50 seconds, the screen will be

- 1. Press ♦/OK when the parent unit is idle.
- 2. Press ▼ or ▲ to choose Sound-activated Screen, then press ♦/OK
- Press ▼ or ▲ to choose On or Off, then press ♦/OK to confirm your selection. The screen returns to main menu.

• If the sound sensitivity is set to **Highest**, the parent unit screen may remain on con even though sound activation is on.

#### Zoom

You can zoom in or out while viewing images from baby unit.

- Press 

  to zoom in.
- zoomed image up, down, left or right correspondingly
- Press ⊕ again to zoom out.

You can use the TALK function of the parent unit to comfort your baby.

- 1. Press and hold (4) on the parent unit. The (4) light turns on 2. Speak towards the microphone (1) on the
- parent unit. Your voice is broadcast to the

Important safety

instructions

the product.

2. Adult setup is required.

a wet basement or shower.

3. Release the (1/2 key to stop the broadcast. The (1/2 light goes off.

When using your equipment, basic safety precautions

Follow all warnings and instructions marked on

a substitute for responsible and proper adult

supervision and should not be used as such.

5. Do not use this product near water. For example,

do not use it next to a bath tub, wash bowl.

6. CAUTION: Use only the batteries indicated in

7. Use only the adaptors included with this

seriously damage the product.

Use a damp cloth for cleaning.

11. Unplug the power cords before replacing

12. Do not cut off the power adaptors to replace

them with other plugs, as this causes a

13. Do not allow anything to rest on the power cords.

14. This product should be operated only from the

Do not install this product where the cords may

type of power source indicated on the marking

label. If you are not sure of the type of power

15. Do not overload wall outlets or use an extension

16. Do not place this product on an unstable table.

17. This product should not be placed in any area

and openings in the back or bottom of this

where proper ventilation is not provided. Slots

product are provided for ventilation. To protect

them from overheating, these openings must not be blocked by placing the product on a soft

shelf, stand or other unstable surfaces.

supply in your home, consult your dealer or local

cabinet outlet.

easily accessible.

hazardous situation

be walked on or crimped.

This product is not intended for use as a medical

kitchen sink, laundry tub or swimming pool, or in

this manual. There may be a risk of explosion

if a wrong type of battery is used for the parent

unit. Use only the supplied rechargeable battery.

product. Incorrect adaptor polarity or voltage can

Baby unit power adaptor: Output: 5.9V DC 1A

Parent unit power adaptor: Output: 5V DC 1A.

oriented in a vertical or floor mount position. The

prongs are not designed to hold the plug in place

8. The power adaptors are intended to be correctly

9. For pluggable equipment, the socket-outlet shall

be installed near the equipment and shall be

cleaning. Do not use liquid or aerosol cleaners.

10. Unplug this product from the wall outlet before

should always be followed to reduce the risk of fire,

electric shock and injury, including the following:

3. This product is intended as an aid. It is not

#### Set the alert

Low battery tone You can set the parent unit to beep when the

- parent unit operates in low battery conditions. 1. Press ♦/OK when the parent unit is idle.
- 2. Press ▼ or ▲ to choose Alert Tone, then
- press ->/OK 3. Press ♦/OK again to choose Low Battery
- 4. Press ▼ or ▲ to choose **On** or **Off**, then
- press ♦/OK to confirm your selection.

#### No link alert

You can set the parent unit to beep when the link between the parent unit and the baby unit is lost.

1. Press ♦/OK when the parent unit is idle.

3. Press ▼ or ▲ to choose No Link Alert, then

- 2. Press ▼ or ▲ to choose Alert Tone, then press ->/OK
- press -♦/OK 4. Press ▼ or ▲ to choose On or Off, then
- press  $\Rightarrow$ /OK to confirm your selection.

#### Sound alert

You can turn on the sound alert feature so that the parent unit beeps and displays Sound detected at CAM # whenever the baby unit detects sounds.

- 1. Press  $\frac{1}{2}$ /OK when the parent unit is idle.
- 2. Press ▼ or ▲ to choose Alert Tone, then press ♦/OK to select.
- 3. Press ▼ or ▲ to choose Sound alert, then press ->/OK
- 4. Press ▼ or ▲ to choose On or Off, then press  $\Rightarrow$ /OK to confirm your selection.

heat register.

components.

scanners, etc.

**Cautions** 

· The sound alert feature is only available in SPLIT-VIEW mode

surface such as a bed, sofa or rug. This product

should never be placed near or over a radiator or

dangerous voltage points or create a short circuit.

18. Never push objects of any kind into this product

through the slots because they may touch

Never spill liquid of any kind on the product.

not disassemble this product, but take it to

an authorised service facility. Opening or

removing parts of the product other than

specified access doors may expose you to

dangerous voltages or other risks. Incorrect

20. You should test the sound reception every

reassembling can cause electric shock when

time you turn on the units or move one of the

21. Periodically examine all components for damage.

22. Be aware of possible loss of privacy while using

23. Children should be supervised to ensure that

24. The product is not intended for use by persons

experience and knowledge, unless they have

SAVE THESE INSTRUCTIONS

2. Do not expose the product to extreme cold, heat

3. Batteries should not be exposed to excessive

4. Make sure the baby unit and the adaptor cord

are always out of reach of the baby, at least

3 feet away from the baby or cot, to avoid a

with anything such as a towel or a blanket.

installing your baby monitor as far away from

these electronic devices as possible: wireless

routers, radios, mobile phones, intercoms,

computers, kitchen appliances and cordless

room monitors, televisions, personal

interference with your baby monitor. Try

Never place the baby unit inside the baby's cot or

playpen. Never cover the baby unit or parent unit

heat such as bright sunshine or fire.

possible strangulation hazard.

6. Other electronic products may cause

or direct sunlight. Do not put the product close to

1. Use and store the product at a temperature

between 0°C and 39°C.

a heating source.

been given supervision or instruction concerning

use of the appliance by a person responsible for

(including children) with reduced physical.

sensory or mental capabilities, or lack of

they do not play with the product.

public airwaves. Conversations may be picked

up by other nursery monitors, cordless phones,

19. To reduce the risk of electric shock, do

the product is subsequently used.

## Monitor the temperature

Your baby unit monitors the temperature of your baby's room with its built-in temperature sensor. If the detected temperature is outside of the preset temperature range, the parent unit will display an alert message.

#### Set temperature range

You can set the desired room temperature alert range. The minimum temperature can be set between 52 °F (11 °C) and 69 °F (20 °C). The maximum temperature can be set between 70 °F (21 °C) and 86 °F (30 °C)

- 2. Press ▼ or ▲ to choose **Temperature**, then press ÷/OK
- 3. Press ▼ or ▲ to choose Minimum or

1. Press ♦/OK when the parent unit is idle.

- Maximum, then press ♦/OK
- 4. Press ▼ or ▲ to choose the desired minimum or maximum temperature, then press  $\Rightarrow$ /OK to confirm your selection.

#### Temperature alert tone

You can turn on the temperature alert tone so that the parent unit will emit an alert tone if the detected temperature is out of range.

- 1. Press  $\Rightarrow$ /OK when the parent unit is idle.
- 2. Press ▼ or ▲ to choose **Temperature**, then press ->/OK
- 3. Press ▼ or ▲ to choose Alert Tone, then
- 4. Press **▼** or **△** to choose **On** or **Off**, then press ♦/OK to confirm your selection.

#### Temperature format

selection

**IMPORTANT** 

Customer Service

happy to help you

You can choose to display the temperature in Fahrenheit (°F) or Celsius (°C).

- 1. Press  $\frac{1}{2}$ /OK when the parent unit is idle. 2. Press ▼ or ▲ to choose **Temperature**, then
- press ->/OK. 3. Press ▼ or ▲ to choose **Format**, then press

Customer service and

Please retain this booklet with your sales receipt as

Please call our Consumer Services Department on

(outside UK) and a service representative will be

PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login

to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.

PRODUCT WARRANTY

e is covered by a one year warranty from the date of terials or workmanship.

The product may be returned to the place of purchase. Alternatively the product can returned to VTech Electronics Europe pic (see address below), with proof of purchase without proof of purchase no replacement will be provided.

Tech Electronics Europe plc will examine the product and if it is found to be defective to faulty materials or workmanship, will replace the product at their discretion.

If the product covered by this warranty is damaged due to misuse, modification of unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.

Returns to VTech Electronics Europe plc should include a cheque or postal order fc1.50 towards the cost of return postage and packaging.

To keep an online record of your warranty, please register your product online at ww

, ech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, Wes illam, DE7 6HE

S WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT

s warranty is valid for the UK and Eire only. For products purchased of UK and Eire, please contact your local distributor or place of pur-

his warranty is personal to the original purchaser and is not transferal

Products returned to VTech Electronics Europe plc, should be addressed as packed carefully to avoid damage in transit (Please do not include batteries Please include details of the fault together with your name and address.

Breakages to the LCD screen are not covered by the warranty.

01235 546810 (from UK) or +44 1235 546810

product warranty

proof of the date of purchase

♦/OK. 4. Press ▼ or ▲ to choose Fahrenheit or **Celsius**, then press **♦**/OK to confirm your

#### Turn the vibration on or off

3. Press ▼ or ▲ to choose On or Off.

Rename the baby unit

the sub-menu of below options

4. Press ♦/OK to confirm your selection.

You can rename your baby unit. Once the

baby unit is renamed, its new name together

with the baby unit number (1) will appear in

1. Press  $\Rightarrow$ /OK when the parent unit is idle.

3. Press  $\Rightarrow$ /OK to select the baby unit.

confirm your selection.

2. Press **▼** or **▲** to choose **Rename**, then press

4. Press ▼ or ▲ to choose the desired name

The baby unit has infrared LEDs that allow you

to see your baby clearly at night or in a dark

detects low light levels, the infrared LEDs are

switched on automatically. The images from

· It is normal if you see a short white glare on your

When the infrared LEDs are on, the image is in

black and white. This is normal due to external

Technical specifications

4.3" Colour LCD

Parent unit battery

BYD SCD530-4

3.7V Li-polymer battery

Baby unit power adaptor

EU: Tenpao S006AKV0590100

UK: Tenpao S006AKB0590100

Input: 100-240VAC, 50/60Hz,

EU: Tenpao S006MV0500100

UK: Tenpao S006MB0500100

Input: 100-240VAC, 50/60Hz,

For pluggable equipment, the

shall be easily accessible.

300mA, Output: 5VDC, 1000mA

socket-outlet (power adaptor) shall

be installed near the equipment and

Parent unit power adaptor

200mA, Output: 5.9VDC, 1000mA

parent unit screen as the baby unit is adapting to

the baby unit is in black and white, and  $\supset$ 

room. When the baby unit being viewed

for the baby unit, then press ♦/OK to

press <del>\$</del>/OK.

Sensitivity

Temperature

Night vision

appears on screen

the dark environment

light sources.

**6**NOTES

You can turn on the vibration feature so that the parent unit vibrates when it receives any of To keep this product working well and looking good, Low battery tone, No link alert, Sound alert or **Temperature alert tone** after turning on Avoid putting it near heating appliances and devices the respective alert tones that generate electrical noise (for example, motors or

1. Press ♦/OK when the parent unit is idle. 2. Press ▼ or ▲ to choose **Vibration**, then

Rename

Pair/Unpair

 Avoid dropping the product or treating it roughly Clean with a soft cloth.

fluorescent lamps).

• DO NOT immerse the parent unit and the baby

General product care

unit in water and do not clean them under the tap • DO NOT use cleaning spray or liquid cleaners.

• DO NOT expose it to direct sunlight or moisture.

· Make sure the baby unit and parent unit are dry

## Storage

When you are not going to use the baby monitor for some time, remove the rechargeable battery from

baby monitor

listed) for a common cure:

- 1. Disconnect the power to the
- parent unit. Then install the batteries again.
- 3. Wait a few seconds before connecting power back to the baby unit and the parent unit.
- parent unit. 5. Wait for the parent unit to synchronise with the baby unit.
- to take place.

# CZTIP

Frequency

frequency

Channels

LCD

Nominal

effective

requirements

range

control

 Depending on the surroundings and other interfering factors, like lights, objects, colours and backgrounds, the display resolution may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display

Crystal controlled PLL synthesises

Baby unit: 2406 - 2475 MHz

Parent unit: 2406 - 2475 MHz

(WQVGA 480x272 pixel)

Actual operating range may

conditions at the time of use.

vary according to environmental

# Disposal of batteries and

The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the



The chemical symbols Hg, Cd or Pb. where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in

Battery Directive (2006/66/EC). The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly

## **Declaration of Conformity**

This product is intended for use within Europe. This equipment compiles with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.


Vtech Telecommunications Ltd. hereby declares that this Digital Audio Baby Monitor BM4200 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformity for the BM4200 is available from http://www.vtech.com/rtte-directive.

The Background Noise sound file was created by Caroline Ford, and is used under the Creative Commons license. The Stream Noise sound file was created by Caroline Ford, and is used under the Creative Commons license The Crickets At Night sound file was created by Mike Koenig, and is used under the Creative Commons license. The Heart Beat sound file was created by Zarabadeu, and is

used under the Creative Commons license





# Specifications are subject to change without notice.

before you connect them to the mains again.

not respond

the parent unit. Store the parent unit, the baby unit and the adaptors in a cool and dry place.

Frequently asked questions

## Below are the questions most frequently asked about

the baby monitor Try the following (in the order

> baby unit and the parent unit. . Remove the batteries in the

- 4. Turn on the baby unit and the
- Allow up to one minute for this

# product

