

User's Manual

Baby's 1st Smartphone



© 2013 VTech Printed in China 91-002845-001 (R)

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

deline

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

- ...challenging activities that can keep pace with my growing mind
- ...intelligent technology that adapts to my level of learning
- ...National Curriculum based content to support what I'm learning at school

l want...

- ...to get ready for school by starting to learn the alphabet and counting
- ...my learning to be as fun, easy and exciting as can be
- ...to show mv creativity with drawing and music so my whole brain develops

lam...

vtech Bay

Toys that will

...responding to colours, sounds and textures

stimulate their interest

in different textures. sounds and colours

- ...understanding cause and effect
- ...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36months





To learn more about this and other VTech® products, visit <u>www.vtechuk.com</u>

INTRODUCTION

Thank you for purchasing the VTech® Baby's 1st Smartphone learning toy!

The **Baby's 1st Smartphone** by **VTech®** introduces baby to the smartphone world. Special apps allow baby to call home or animal friends, check the weather or even organise their day just like mum and dad.



INCLUDED IN THIS PACKAGE

- One Baby's 1st Smartphone
- One user's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned **OFF**.
- Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
- Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit: www.recycle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES

1. ON/OFF SWITCH




2. AUTOMATIC SHUT-OFF

To preserve the battery life, the VTech® Baby's 1st Smartphone will automatically power-down after approximately 18 seconds without input. The unit can be turned on again by sliding the mode switch or pressing any of the three buttons below the touch screen

3. MODES OF PLAY

Switch between App Mode and Music Mode by sliding the mode switch left or right.



4. APP MODE


TOUCH SCREEN ICONS

Press the 12 touch screen app icons for pretend play and to learn about letters, numbers, shapes and more. These icons also act as phone keys to dial numbers. Slide your finger on the touch screen continuously for playful sound effects with various light patterns.



HOME ICON

You can enter a special number on the **Baby's 1st Smartphone**. Press and hold the home icon () for three seconds, then dial the number you want to record. Press the star button to save the number. After recording, press the home icon again to play the saved number.



5. MUSIC MODE

TOUCH SCREEN ICONS

Press the music note and instrument icons to hear short tunes and sounds from different instruments.



PLAY PREVIOUS/PLAY & PAUSE/PLAY NEXT BUTTON



6. ADDITIONAL FUN ACTIVITIES

STAR BUTTON

When you press the **star button** ((a)), you will be asked to touch the flashing light. Touching the correct icon will result in rewarding sound effects.



CALL & HANG-UP BUTTONS

Press the **call** () and **hang-up** () **buttons** to imitate using the phone for calls.



MELODY LIST

- Mary Had a Little Lamb
- 2. Teddy Bears' Picnic
- 3. Pat-a-Cake
- 4. Here We Go 'Round the Mulberry Bush
- 5. Yankee Doodle
- A-Tisket, A-Tasket
- 7. Camptown Races
- 8. Bingo
- 9. Polly Put the Kettle On
- 10. London Bridge

SONG LYRICS

SONG 1

Hello, hello! It's learning on the go!

SONG 2

Music? Check! Dancing's in effect!

SONG 3

One, one two, one two three four five. Six, seven, eight and nine.

SONG 4

Circle, square, triangle, all these shapes are wonderful.

SONG 5

Wake up. Wake up. The sun is rising. Good morning!

SONG 6

Ah-buh-kuh, sing with me!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING


If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON.** The unit should now be ready to play again.
- 5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing VTech® products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.





vtech PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.



- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).

Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.