

vtech[®]

Parent's Guide



Gear Up & Go Lion



91-003456-001 UK

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® GearZooz® Gear Up & Go Lion**. This adorable Lion includes a Smart Gear™ Mouse and introduces animals, tells stories and plays fun songs. Place the Smart Gear™ Mouse on the Purple Smart Pole to hear fun stories and responses, or create a silly song with Mouse sound effects. Then, connect the gears and turn the handle gear to watch the gears spin.



INCLUDED IN THIS PACKAGE


- One **GearZooz® Gear Up & Go Lion**
- One **Smart Gear™ Mouse**
- One **parent's guide**

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep this parent's guide as it contains important information.


Unlock the packaging locks:



- ① Rotate the packaging locks anticlockwise 90 degrees.
- ② Pull out the packing locks.

Unlock the Smart Gear™ Mouse:


1. Slide the white tab to the right to unlock the **Smart Gear™ Mouse**.
2. Lift the tab and **Smart Gear™ Mouse** off the Lion.
3. Cut the string between the white tab and **Smart Gear™ Mouse**, then discard the string and tab.



GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the side of the unit.
3. Use a screwdriver to loosen the screw and open the battery cover.
4. Install 2 new AAA (AM-4/LR03) batteries into the battery box as illustrated. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelee bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

PRODUCT FEATURES & ACTIVITIES

1. Off/Low/High Volume Switch



Slide the **Off/Low/High Volume Switch** to the **Low** or **High Volume** position to turn the Lion on. Slide the **Off/Low/High Volume Switch** to the **Off** position to turn the Lion off.

2. Light Up Button



Press the **Light Up Button** to learn about the Lion or listen to a story when there is a **Smart Gear™ Animal** on the **Purple Smart Pole**. The lights will flash with the fun responses, melodies and songs.

3. Purple Smart Pole



Place a **Smart Gear™ Animal** on the **Purple Smart Pole** to hear a story, learn about the animal, or to add fun animal sounds into songs.

4. Smart Gear™ Animals



Mix and match your **Smart Gear™ Animal** with any other **GearZooz®** products. Place the **Smart Gear™ Animal** on a **Purple Smart Pole** to play and hear responses.

5. Trigger Handle Gear



Turn the **Trigger Handle Gear** to hear a melody. Turn the **Trigger Handle Gear** faster to make the melody play faster.

6. Push Along



Push the Lion to hear fun songs.

7. Automatic Shut Off

To preserve battery life, the **GearZooz® Gear Up & Go Lion** will shut off automatically after several minutes without any input. The Lion can be turned on again by sliding the **Off/Low/High Volume Switch**. The Lion will also automatically turn off when the batteries are very low. When this happens we suggest installing a brand new set of batteries.

TO BEGIN PLAY

Move the **Off/Low/High Volume Switch** to the **Low** or **High Volume** position to play.

Activate Normal Play Mode:

The **GearZooz® Gear Up & Go Lion** is in a TRY-ME mode in the packaging. To activate normal play mode, turn the Lion on. Place any **Smart Gear™ Animal** on the **Purple Smart Pole**. You will hear a short melody notifying you that normal game play has been activated.

Note: Be sure to remove the white tab from under the **Smart Gear™ Mouse** before playing.

SING-ALONG SONG LIST

1. Lions live in prides,
Lions live outside,
We like to lay in the sun all day,
Our roars are heard worldwide!
2. Let's go! It's story time!
We'll learn how to be kind,
Friendly and caring! Yay!
Let's go! It's story time!
3. Mouse is my good buddy,
He rides with me, he's so funny,
We cruise all around,
Laughing the day away!

MELODY LIST

1. Hey Diddle Diddle
2. Did You Ever See a Lassie?
3. Clementine
4. Old MacDonald
5. Hickory Dickory Dock

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the metal parts on the purple Smart Pole clean by wiping them.
3. Keep the unit out of direct sunlight and away from any direct heat source.
4. Remove the batteries when the unit will not be in use for an extended period of time.
5. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

TECHNICAL SUPPORT

If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to assist you.

Before requesting support, please be ready to provide or include the information below:

- The name of your product or model number (the model number is typically located on the back or bottom of your product).
- The actual problem you are experiencing.
- The actions you took right before the problem started.

Internet: www.vtech.co.uk

Phone: 01235 546810 (from UK), or +44 1235 546810 (outside UK)

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.



CLASS 1
LED PRODUCT



PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login
to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
9. To keep an online record of your warranty, please register your product online at www.vtech.co.uk/warranty

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.



**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk



TM & © 2018 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003456-001 