

vtech[®]

User's Manual

Little Love Baby Talk



© 2014 VTech
Printed in China
91-002942-006 UK

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION

Thank you for purchasing the **VTech® Little Love™ Baby Talk!** Talk to your baby! The more your little one talks to Baby the more words and phrases she will learn and repeat! Includes over 80 adorable baby phrases and real-life sound effects like drinking and giggling.



3 Vocabulary books:



1. My Home



2. Food Fun



3. Animals

INCLUDED IN THIS PACKAGE

- One VTech® Little Love™ Baby Talk
- One dummy
- One bottle
- Three vocabulary books
- One User's Manual

WARNING: All packing materials such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep user's manual as it contains important information.

GETTING STARTED


Activate the Baby to start from newborn

After removing the baby doll from the packaging, put the dummy in her mouth, then remove to activate from the newborn mode.



BATTERY INSTALLATION

1. Open the hook and loop opening on the doll's back.
2. Make sure the unit is turned **OFF**.
3. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
5. Replace the battery cover and secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product




The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Help protect the environment by disposing of your product or batteries responsibly.



For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

NOTE:

The cord located on the hands is not part of this toy. This cord should be removed and discarded for your child's safety.



PRODUCT FEATURES

1. VOLUME/ OFF SWITCH



Slide the **Volume/Off Switch** to the required volume level to turn the unit on or adjust the volume.

2. TALK WITH ME BUTTON



Press the **Talk with Me Button** and baby will invite you to talk to her. When you say something she will imitate what you said!

3. READING BUTTON



Press the **Reading Button** to choose from 3 vocabulary books to read with your baby. Read aloud to baby, listen to baby read to you or teach baby to read!

4. CARING BUTTON



Press the **Caring Button** to love and care for your baby by responding to her requests.

5. MUSIC BUTTON



Press the **Music Button** to listen to baby coo and sing-along to nursery rhymes.

6. DUMMY

Insert the **Dummy** into baby's mouth to hear cute sucking sounds.



7. BOTTLE

Insert the **Bottle** into baby's mouth to feed her.



8. NEWBORN BUTTON

Pressing the **Newborn Button** will reset the baby to newborn mode. The baby will forget all previous knowledge and you can experience the learning process all over again.



9. TURNING THE UNIT OFF/ AUTOMATIC SHUT-OFF

Slide the **Volume/Off switch** to **OFF** to turn the unit off. To preserve battery life, the unit will automatically power-off after several minutes without input.


ACTIVITIES

1. Talk with Me

Baby Talk will invite you to talk to her. When the red bow on baby's head lights-up, talk to her and she will imitate what you say!



To ensure Baby can listen clearly, please speak towards baby's front at a distance of 25cm.



2. READING

You can choose from 3 vocabulary books to read with Baby. First of all she will ask you to read words to her, as she grows and learns she will encourage reading together and read the words to you.



3. CARING

Baby may get hungry or want her dummy. Respond to her requests by giving her the bottle or dummy.




4. MUSIC TIME

Baby will coo and sing along with nursery rhymes.



5. NEWBORN MODE

If you want to experience the learning process all over again, pressing the Newborn button will reset the baby to newborn mode. The baby will forget all previous knowledge.



CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit ON. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1
LED PRODUCT



PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

