


**vtech®**

# Parent's Guide

## **SWITCH&GO®** **DiNOS** *Boost the Brachiosaurus*



91-003472-001 

**VTech** understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

## **Pre-School**

Interactive toys to develop their imagination and encourage language development

## **vtech Baby**

Toys that will stimulate their interest in different textures, sounds and colours

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

**Birth-36 months**



### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

**3-6 years**



## **Electronic Learning Computers**

Cool, aspirational and inspiring computers for curriculum related learning

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


**4-10 years**



To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Introducing **Boost the Brachiosaurus**. With a few simple steps, Boost can switch into a truck and back again! Press Boost's action button to move his head back and forth. By interacting with Boost, your child can learn fun dinosaur facts as they play!



# INCLUDED IN THIS PACKAGE

- One VTech® SWITCH & GO DINOS® Boost the Brachiosaurus
- One parent's guide

## WARNING:


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

## NOTE:


Please keep this parent's guide as it contains important information.

## IMPORTANT NOTE:

**For your child's safety, only use Boost the Brachiosaurus on hard, flat surfaces. Do not put Boost in either configuration on your clothing, body or hair.**



**Unlock the packaging locks:**



① Rotate the packaging locks 90 degrees anticlockwise.


② Pull out the packaging locks.

# GETTING STARTED

## BATTERY INSTALLATION

1. Make sure the dino is turned **OFF**.
2. Locate the battery cover on the bottom of the panel.
3. Use a screwdriver to open the cover.
4. Install 2 new AA size (LR6/AM-3) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure.

**Note: If there is no response when Boost is switched ON, please install brand new batteries and try switching Boost ON again.**



## BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metal-hydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## Disposal of batteries and product



The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

## PRODUCT FEATURES

### 1. ON/OFF/VOLUME SWITCH

Slide the **ON/OFF/VOLUME SWITCH** to the **LOW VOLUME** or the **HIGH VOLUME** position to turn the dino **ON**.

To turn the dino **OFF**, slide the switch to the **OFF** position.



### 2. TALK BUTTON

Press the **TALK BUTTON** to hear fun phrases and cool dino facts!



### 3. SOUND EFFECTS BUTTON

Press the **SOUND EFFECTS BUTTON** to hear cool dino and truck sound effects!




### 4. ACTION BUTTON

Press the **ACTION BUTTON** to move **Boost's** head back and forth when in dino mode!




### 5. LCD SCREEN

The **LCD SCREEN** will display animated dino eyes and driver.



### 6. TRAILER

Connect the **TRAILER** to the back of **Boost** in either dino or vehicle mode. Open up the back of the **TRAILER** to load and store other **SWITCH & GO DINOS®** (sold separately).



### 7. AUTOMATIC SHUT OFF

To preserve battery life, **Boost the Brachiosaurus** will shut off automatically after several minutes without input. **Boost** can be turned on again by pressing any button.

**Note:** If **Boost** repeatedly shuts off, or has abnormal responses when switched on, please install brand new batteries and try switching **Boost** on again.

# ACTIVITIES


## 1. Dino Mode

In dino mode, pressing the **TALK BUTTON** will play fun phrases and cool dino facts. Switching **Boost** and moving him around will trigger lively dino sound effects.


## 2. Vehicle Mode

In vehicle mode, **Boost** will say fun and encouraging driver phrases when the **TALK BUTTON** is pressed. Switching **Boost** and moving him around will trigger lively truck sound effects.

## HOW TO SWITCH BOOST FROM DINO TO VEHICLE




1. Press **Boost's** head down into his body.




2. Fold the left and right hind legs of **Boost** up to the sides of his head.






3. Fold the left and right front legs of **Boost** back into a horizontal position.



4. Fold down the blue section of **Boost's** tail, then push the red section of the tail inwards to complete the cab.



5. As shown in the above figure, connect the trailer to the rear of the cab to complete the switch from dino mode to vehicle mode.

### Note:

To switch Boost back into a dino, follow the above steps in reverse order.

## CARE & MAINTENANCE

1. Keep the dino clean by wiping it with a slightly damp cloth.
2. Keep the dino out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the dino will not be in use for an extended period of time.
4. Do not drop the dino on hard surfaces and do not expose the dino to moisture or water.

## TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the dino **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the dino stand for a few minutes, then replace the batteries.
4. Turn the dino **ON**. The dino should now be ready to play with again.
5. If the dino still does not work, install a brand new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

### **IMPORTANT NOTE:**

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) with any problems and/or suggestions that you might have. A service representative will be happy to help you.



**CLASS 1  
LED PRODUCT**



# PRODUCT REGISTRATION

Visit [www.vtech.co.uk/clubvtech/login](http://www.vtech.co.uk/clubvtech/login)  
to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



## PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
9. To keep an online record of your warranty, please register your product online at [www.vtech.co.uk/warranty](http://www.vtech.co.uk/warranty)

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***[www.vtech.co.uk](http://www.vtech.co.uk)***



TM & © 2018 VTech Holdings Limited.  
All rights reserved.  
**Printed in China.**  
91-003472-001 