

Parent's Guide



Animal Boat

















VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

Pre-School

Interactive toys to develop their imagination and encourage language development Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

vtech Bally

Toys that will stimulate their interest in different textures, sounds and colours

l want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

...understanding cause

lam...

and effect

...responding to colours,

sounds and textures

...learning to touch, reach, grasp, sit-up, crawl and toddle








To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the VTech® Toot-Toot Animals Animal Boat learning toy!

Welcome onboard the **Animal Boat!** Learn how to count from 1-6 by dropping the 6 roly-poly animals into the counting tunnel. Place a SmartPoint™ animal on the desk SmartPoint™ to hear phrases, sounds and to open the door to release the roly-poly animals! Press the 4 light up buttons to learn all about colours and weather at sea.



INCLUDED IN THIS PACKAGE



One Toot-Toot
Animals Animal Boat




One label sheet



Six roly-poly animals

- One parent's guide

Please stick the labels to the Animal Boat securely as indicated below:





WARNING:

All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety


NOTE:

Please keep the parent's guide as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the bottom of the unit. Use screwdriver to loosen the screw.
- Install 3 new AAA (LR03/AM-4)
 batteries following the diagram inside
 the battery box. (The use of new
 alkaline batteries is recommended for
 maximum performance).
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- · Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- · Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.

- · Do not dispose of batteries in fire.
- · Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.


Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

Unlock the packaging locks:



- Rotate the packaging locks 90 degrees anticlockwise.
- ② Pull out the packaging locks.

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the ON/
OFF/VOLUME CONTROL SWITCH
to the LOW VOLUME (♠)) or HIGH
VOLUME (♠)) position. To turn
the unit OFF. slide the ON/OFF/
VOLUME CONTROL SWITCH to the
OFF (ஶ) position.



2. AUTOMATIC SHUT OFF

To preserve battery life, the VTech® Toot-Toot Animals Animal Boat will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing any button or by dropping the roly-poly animals into the tunnel.



ACTIVITIES

 Slide the ON/OFF/VOLUME CONTROL SWITCH to the LOW VOLUME (4)) or HIGH VOLUME (4))) position to the unit ON. You will hear a song and a welcoming phrase. The lights will flash with the sounds.



- Press the 4 LIGHT UP BUTTONS to learn about weather and colours. You will also hear a variety of short tunes and melodies. The lights will flash with the sounds.
- 3. Drop a ROLY-POLY ANIMAL into the counting tunnel to learn counting numbers from 1 to 6. The lights will flash with the sounds. Press down the on the DESK BUTTON to open the boat's door and to hear fun sounds. Place any SmartPoint™ animal (each sold separately) over the SmartPoint™ location on the DESK BUTTON to trigger fun sounds, songs or phrases. The lights will flash with the sounds.
- Pull the **Animal Boat** along to activate the motion sensor and to hear melodies and jam fun sounds on top of the melodies. The lights will flash with the sounds.







MELODY LIST

- 1. Animal Fair
- 2. Bear Went Over the Mountain
- 3. Bingo
- 4. Froggie Went a A-Courting
- 5. Hickory Dickory Dock
- 6. Humpty Dumpty
- 7. Jack and Jill

- 8. Down By the Riverside
- 9. Mary Had a Little Lamb
- 10. My Bonnie Lies Over the Ocean
- 11. Old MacDonald Had a Farm
- 12. Row, Row, Row Your Boat
- 13. Sailing, Sailing (over the bounding main)
- 14. London Bridge
- 15. Skip to My Lou

SING-ALONG SONG LYRICS

SONG 1

All aboard the animal boat, for adventure at sea, rolling, sliding you'll have fun, riding around with me!

SONG 2

Gather around, 1, 2, 3, 4, time to go, let's get on board.

SONG 3

Time to relax and have lots of fun, take in the views and enjoy the sun.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the **Animal Boat** stops working or malfunctions, please follow these steps:

- Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit sit for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- 5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1 LED PRODUCT



PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- 3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- 7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
- To keep an online record of your warranty, please register your product online at www. vtech.co.uk/warranty

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.



Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk

