

vtech[®]

Instruction Manual

Sparkle & Shine Unicorn



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech *Baby*

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

This super cute unicorn comes in its very own play set handbag that opens and transforms into a unicorn bed! Care for your unicorn with the included nappy, bottle and teddy bear. Light up horn glows & projects light patterns in bed mode for soothing play.

Light Up
Horn Button



Mouth Button

Tummy Button

Light Sensor

Off/Low/High
Volume Selector



Little Bear



Nappy



Handbag



Milk Bottle



Quilt

INCLUDED IN THIS PACKAGE

- One Sparkle & Shine Unicorn
- Quick Start Guide


WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks



- ① Rotate the packaging locks 90 degrees anti-clockwise.
- ② Pull out the packaging locks and discard.

Cleaning suggestion:

The unicorn can be wiped clean only. The fabric accessories can be washed.




GETTING STARTED

The unicorn is in try-me mode in the packaging. To exit try-me mode, just slide the **Off/Low/High Volume Selector** from OFF to either of the Low/High Volume positions to turn the unit on.

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

WARNING:

Not suitable for children under 36 months. Small parts and long cord.
Choking and strangulation hazards.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

Product Features

1. Off/Low/High Volume Selector

To turn the unit On, slide the **Off/Low/High Volume Selector** to the **Low Volume** or **High Volume** position. To turn the unit Off, slide the **Off/Low/High Volume Selector** to the **Off** position.



2. Light Up Horn Button

Press the **Light Up Horn Button** to sing adorable songs and hear the sweet child-friendly melodies with the unicorn while sitting. Listen to soothing lullabies while lying down.



3. Mouth Button

Trigger fun sound effects with the dummy & milk bottle.



4. Tummy Button

Press the **Tummy Button** to hear sweet phrases & feelings.



5. Seat and Pillow

The unicorn likes to sit properly in the seat in the handbag and will say “Comfy chair!”. She feels relaxed when she is lying on the pillow properly and will say “Comfy bed!”


6. Colour Projection Light

The **Colour Pojection Light** will flash or slowly fade in and out with the music to enhance the interactive play. It will be projected into the handbag when the unicorn is lying on the bed.




7. Motion Sensor

When the is sitting or lying down the sensors will trigger different reactions and play.



8. Light Sensor

In a low-light environment, open or close the hangbag and if the unicorn is sitting on the seat she will interact with you.



Note:

The light sensor function requires a low-light environment. It is recommended to operate indoors or in dim light environments.

9. Automatic Shut-Off

To preserve battery life, the **Sparkle & Shine Unicorn** will automatically power down after several seconds without input. But in Sleeping Bed Mode, it will automatically power down after playing lullabies for about 20 minutes. The unit can be turned on again by pressing any button.

Note:

If the unit repeatedly powers down while playing, please insert new batteries and try switching it on again.

ACTIVIES

1. Hangbag Mode

The unicorn would like to go for a walk with you. Close the hangbag and carry your bag along. Press the Horn Button and she will sing a variety of fun songs for you.

2. Playhouse Mode

Enjoy adorable songs and melodies with your unicorn by pressing the Horn Button when the unicorn is sitting in the seat. Use the dummy and milk bottle to play nurturing games. Press the Tummy Button to hear sweet phrases and feelings.

3. Sleeping Bed Mode

Lay the **Sparkle & Shine Unicorn** down on the pillow of the bed, press the Horn Button and various soothing lullabies will play continuously for about 20 minutes to soothe her to sleep. The magical colour projection light will slowly fade in and out with the lullabies and be displayed on the handbag.

4. Out of the Sleeping Bed Mode

Sparkle & Shine Unicorn needs you to cuddle & care for her. Pick her up from the seat, press the Horn, Mouth and Tummy button and enjoy interactive time with her. Hug her, help to soothe and rock her to sleep with a relaxing lullaby by pressing the Horn Button. Use the dummy or milk bottle to soothe her, she will tell you what she likes when you press the Tummy Button.

SING-ALONG SONG LYRICS

SONG 1

Hey, Let's go along to the park,
along to the park,
along to the park,

Hey, Let's go to the park and have fun today!

SONG 2

Carry me in my handbag house,
handbag house, handbag house,
Carry me in my handbag house,
while I play with my toys.

SONG 3

Sing, Sing, Sing with me,
Let's have lots of fun,
Singing together, is a pleasure,
for you and me!

SONG 4

Sparkle & shine, shining bright,
Glimmer & shimmer, shining lights,
Dazzle & glow, Look at my lights,
Magically bright today!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

1. Please turn the unit OFF.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit ON. The unit should now be ready to play with again.
5. If the product still does not work, please install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

