

**vtech**<sup>®</sup>  
Baby

# Parent's Guide

## Peek-a-Boo-Bear



91-003764-001 (UK)

**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **vtech** Baby

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



## **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Introducing the **Peek-a-Boo Bear** by **VTech®**! Baby will get a lovely surprise when they press one of the two learning buttons on the honey pot, as a friendly fabric bear will pop up to play hide and seek! The buttons also play exciting music, catchy songs and fun phrases which support and encourage language development.




# INCLUDED IN THIS PACKAGE

- One Peek-a-Boo-Bear
- One Parent's Guide

**WARNING:** All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy and should be discarded for your child's safety.

**NOTE:** Please keep this Parent's Guide as it contains important information.


Unlock the packaging locks:



## GETTING STARTED

### BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit and use a screwdriver to loosen the screw and open the battery cover.
3. If used or spent batteries are present, remove these batteries from the unit by pulling up on one end of each battery.



4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and tighten the screw to secure the battery cover.

## **BATTERY NOTICE**

- Use new alkaline batteries or fully charged NI-MH (Nickel Metal-hydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## Disposal of batteries and product



The crossed-out wheelee bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

[www.recycle-more.co.uk](http://www.recycle-more.co.uk)

[www.recyclenow.com](http://www.recyclenow.com)

## PRODUCT FEATURES

### 1. On/Off/Volume Switch


To turn the unit **On**, slide the **On/Off/Volume Switch** to the **Low Volume**

◀) or the **High Volume** ▶)) position.

You will hear a cute song and

phrase. To turn the unit **Off**, slide the

**On/Off/Volume Switch** to the **Off** ● position.



### 2. Automatic Shut Off

To preserve battery life, the **Peek-a-Boo-Bear** will automatically shut off after approximately 50 seconds without input. The unit can be turned on again by pressing any button.

**NOTE:** If the unit powers down during play, we suggest changing the batteries.

# ACTIVITIES

## 1. Number Button

When the bear is hiding in the pot, press the **Number Button** to pop up the bear, hear playful peek-a-boo phrases and to learn numbers. If the bear is popped up, press the **Number Button** to hear a cute phrase about the bear. The light will flash with the sounds.




## 2. Music Button

Press the **Music Button** to hear one of three songs and a variety of melodies. If the bear is hiding in the pot, pressing the **Music Button** will pop up the bear. The light will flash with the sounds.




## 3. Hiding Bear

When the soft bear is popped up, press him down so he is hiding in the pot ready to play peek-a-boo. The bear will respond with fun phrases and a playful song. The light will flash with the sounds.



## 4. Bee Slider

Pull down on the **Bee Slider** to spin the spinner and hear phrases about the bees, playful sounds and music. The light will flash with the sounds.



# SONG LYRICS

## Song 1

I'm hiding, are you too?  
Pop up so I can see you.  
Peek-a-boo, peek-a-boo.

## Song 2

Honey is so yummy, in my little tummy,  
It's tasty and sweet, my special little treat!

## Song 3

Circle, triangle, heart and square,  
doo-dah, doo-dah!  
Look around and you will see,  
Shapes are hiding everywhere!

# MELODY LIST

1. There is a Tavern in the Town
2. Teddy Bear's Picnic
3. Hokey Cokey
4. Pop! Goes the Weasel
5. BINGO
6. Alphabet Song
7. Flight of the Bumblebee
8. Au Clair De La Lune
9. Skip to My Lou
10. Toyland
11. Polly Wolly Doodle
12. Here We Go Round the Mulberry Bush
13. Oh Susanna
14. Hickory, Dickory Dock
15. Animal Fair

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

## TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

## CONSUMER SERVICES

Creating and developing **VTech**<sup>®</sup> products is accompanied by a responsibility that we at **VTech**<sup>®</sup> take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

**Australian Customers:**

Phone: 1800 862 155

Website: [support.vtech.com.au](http://support.vtech.com.au)

**NZ Customers:**

Phone: 0800 400 785

Website: [support.vtech.com.au](http://support.vtech.com.au)

## **PRODUCT WARRANTY/ CONSUMER GUARANTEES**


UK Customers:

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

Australian Customers:

### **VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.



**Visit our website for more  
information about our products,  
downloads, resources and more.**

***www.vtech.co.uk***  
***www.vtech.com.au***

