

vtech®

Instruction Manual

MARVEL
SPIDEY
AND HIS AMAZING FRIENDS

SPIDEY-SENSE WALKIE-TALKIES



© MARVEL

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **Spidey-Sense Walkie-Talkies!** Keep in touch indoors and out, at home or on the go with real walkie-talkie communication! These child-safe two-way walkie talkies keep your child's conversations secure, preventing other walkie-talkie users from hearing. Play built-in games on the Spidey and Spin themed handsets!



INCLUDED IN THIS PACKAGE

- Two Spidey-Sense Walkie-Talkies
- One Quick Start Guide


WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.


Unlock the Packaging Locks



- ① Turn the packaging locks anticlockwise several times.
- ② Pull out the packaging locks and discard.

EXIT TRY ME MODE




The Spidey-Sense Walkie-Talkies is in try-me demo mode in the packaging. To exit try-me demo mode, press the ON/OFF Button  to turn ON the unit, then press the Push-to-Talk Button & Volume- Up Button together. When you hear the beep tones and the unit restarts, it means that your Spidey-Sense Walkie-Talkies has exited try-me mode and entered normal play mode.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

1. Make sure the units are turned **OFF**.
2. Locate the battery cover on the back of each unit, turn the battery lock anticlockwise and slide the cover off.
3. If used or spent batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 3 new AAA (LR03/AM-4) batteries into both Walkie Talkies following the diagram inside the battery compartment. (The use of new alkaline batteries is recommended for maximum performance).
5. Replace the battery cover and turn the battery lock clockwise.



WARNING:

Adult Assembly required. Batteries included to be installed by adult before giving to children. Keep batteries out of reach from children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product




The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle

www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES


1. ON/OFF Button

Press this button to turn on the handset. Press this button again to turn the handset off.



2. Push-to-Talk Button

Press and hold this button to transmit your voice to the other handset.



3. Selection Buttons

Choose options and interact with the games with these buttons.



4. Light Button

Push here to change the light mode and personalise the light colour with the selection buttons.



5. Volume Buttons

Press these buttons to adjust the volume.



6. Spider Button

Press to pop-up the cover and hear Spidey phrases! This button also allows interaction with some of the games.



7. Activity Buttons

Press any of these Activity buttons to play a mission game with Spidey.



8. Automatic Shut Off

To preserve battery life, the **Spidey-Sense Walkie-Talkies** will automatically turn off after approximately 18 minutes without input in walkie-talkie mode, or 2 minutes if there is no connection. Turn each handset on again by pressing the **ON/OFF Button**.

ACTIVITIES

When **Spidey-Sense Walkie-Talkies** is turned ON, it is in general mode.

General Mode

Press the **Selection Buttons** to choose the colour for your indication light and then press the **Push-to-Talk Button** to talk. Release the **Push-to-Talk Button** when you are not speaking.

Speak closely into the microphone for the best performance.

Press the **Spider Button** to pop open the cover and hear the Spidey sounds.

Press the **Activity Buttons** to start a mission game.

NOTES:

- When your **Spidey-Sense Walkie-Talkies** is toggling yellow lights, that means the connection to the other handset is lost. Please ensure the other handset is turned ON and within range.
- When your **Spidey-Sense Walkie-Talkies** is toggling red lights and then turned off, that means the batteries need to be replaced.



1.Spidey Stretching

Spidey wants to do some stretching to clear his mind. Follow his instructions and stretch together!



2.Maze Escape

Follow the sequence of lights and sounds then repeat the pattern with the **Selection Buttons** to help Spin escape. Press the **Spider Button** to hear the sequence again.



3.Save the Animals

Help Ghost-Spider save the animals by recognising their sounds and pressing the appropriate **Selection Buttons**. Press the **Spider Button** to hear the sounds again.



4.Calm Hulk

Count with Hulk to calm him down! Hit the **Spider Button** to count whenever the green light glows.



5.Pumpkin Pranks

Help Ms. Marvel stop Gobby's antics. Catch the lights using the **Selection Buttons**.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. If the unit stops working or malfunctions, install a new set of batteries.

DECLARATION OF CONFORMITY

Hereby, VTech Electronics Europe Plc declares that the radio equipment type 5847 is in compliance with The Radio Equipment Regulations 2017 (2017 No.1206). The full text of the Declaration of conformity is available at the following internet address:

www.vtech.com/re-directive

Frequency Band: 2414MHz – 2474MHz

Maximum RF power: 0.01 W (10 dBm)

- * Your Spidey-Sense Walkie-Talkies will achieve the maximum operating range when communicating in flat open areas with no trees or buildings to obstruct the signal. Under these ideal conditions, you may achieve range up to 200m/650' range.
The following conditions tend to reduce the range:
 - One or both walkie talkies are being used indoors.
 - There are large obstructions such as buildings, trees, vehicles, hills, etc. between radios.
 - The batteries are running low.

TROUBLESHOOTING

If for some reason your **Spidey-Sense Walkie-Talkies** stop working or loses connection, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to use again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.



CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

