

Parent's Guide



91-009712-000 ⊮

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...




Electronic Learning

Computers

To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Pop-a-Ball™ Pop & Drop Digger.** This digger comes to life when the multicoloured balls are dropped into the chute. Push the digger along to see the multicoloured balls pop out through the pipe, into the scoop bucket and back again. Pressing the buttons on the digger activates fun role play responses, sounds, music and sing-along songs.



INCLUDED IN THIS PACKAGE

• One Pop & Drop Digger



• One handle



- Four small screws
- · One parent's guide
- WARNING: All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.
- **NOTE:** Please keep this parent's guide as it contains important information.

· Four multicoloured balls



Two large plugs



Unlock the packaging locks:




 Rotate the packaging locks 90 degrees anticlockwise.

2 Pull out the packaging locks.

GETTING STARTED BATTERY INSTALLATION

- 1. Make sure the **Pop & Drop Digger** is turned **OFF**.
- Locate the battery cover on the back of the digger. Use a screwdriver to loosen the screw.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance).



4. Replace the battery cover and tighten the screw to secure.

BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.

- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

ASSEMBLY INSTRUCTIONS

With the **Pop & Drop Digger**, safety comes first. To ensure your child's safety, adult assembly is required.

WARNING! The Pop & Drop Digger contains small screws. For your child's safety, do not let your child play with this toy until it is fully assembled. Adult supervision is recommended. 1. Place the handle over the slot on the digger, making sure that the storage slots on the handle are facing up. Place the two large plugs into the holes on either side of the handle. Then, using a screwdriver, secure two small screws into each of the two large plugs.



PRODUCT FEATURES

 On/Off/Volume Control Switch To turn the digger ON, slide the On/ Off/Volume Control Switch to the Low Volume (■)) or High Volume (■)) position. You will hear a song and a welcoming phrase. To turn the digger OFF, slide the On/Off/Volume Control Switch to the OFF (●) position.



2. Automatic Shut Off

To preserve battery life, the **Pop & Drop Digger** will automatically shut off after approximately 30 seconds without input. The digger can be turned on again by pressing any button or twisting the tyre gear.

NOTE: If the digger repeatedly shuts off, we suggest changing the batteries.

ACTIVITIES

1. Light Up Driver Button

Press the **Light Up Driver Button** to hear a variety of playful phrases, songs, sounds and short tunes. The light will flash with the sounds.



2. Number Buttons

Press the **Number Buttons** to learn about numbers, colours and construction objects, and to hear playful music and sounds. The light will flash with the sounds.

3. Chute

Drop the multicoloured balls into the **Chute** and push the digger along to pop the balls out of the **Pipe**. The balls will be counted as they pop out of the **Pipe**. The scoop bucket will move up and down as the digger is pushed along, scooping the multicoloured balls back into **Chute.** The light will flash with the sounds.





4. Pipe

Drop a ball into the **Pipe** to hear fun sounds. The light will flash with the sounds.



Twist the **Tyre Gear** to the left and then let go to manually pop the balls out of the **Pipe.** You will hear a variety of fun sounds or a short tune. The light will flash with the sounds.

NOTE: Please do not put hands or feet into the **Chute** or **Pipe**. When there is only one ball left in the **Pipe**, you will need to use the **Tyre Gear** to pop the ball out or drop another ball into the **Chute** and push the digger along.





SING-ALONG SONG LIST

SONG 1

I've been working in my digger, All the live long day. I've been working in my digger, Scooping the balls away.

SONG 2

Scoop, scoop, scoop the balls. Clear them off the ground. One, two, three, four, How many have you found?

SONG 3

Scooping up, cleaning the site. Every single day and night!

MELODY LIST

- 1. I've Been Working on the Railroad
- 2. Row, Row, Row Your Boat
- 3. Swing Low, Sweet Chariot
- 4. Turkey in the Straw
- 5. When the Saints Go Marching In
- 6. One Man Went to Mow a Meadow
- 7. Yankee Doodle
- 8. Blow the Man Down
- 9. BINGO
- 10. The Wheels on the Bus

CARE & MAINTENANCE

- 1. Keep the digger clean by wiping it with a slightly damp cloth.
- 2. Keep the digger out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the digger will not be in use for an extended period of time.
- 4. Do not drop the digger onto hard surfaces and do not expose the digger to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the digger OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the digger sit for a few minutes, then replace the batteries.
- 4. Turn the digger **ON**. The digger should now be ready to play with again.
- 5. If the digger still does not work, replace the batteries with a brand new set.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546 810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1 LED PRODUCT

WARNING:

Adult assembly required. This package contains small screws. For your child's safety, do not let your child play with the toy until it is fully assembled.



PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities.



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

- 1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- 3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- 7. Returns to VTech Electronics Europe plc should include a cheque or postal order for ± 1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
 Please include details of the fault together with your name and address.
- 9. To keep an online record of your warranty, please register your product online at www. vtech.co.uk/warranty

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.



Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk



TM & © 2017 VTech Holdings Limited. All rights reserved. **Printed in China.** 91-009712-000 @