

## Roar & Explore Wheel



**VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...**

## **vtech** Baby

**Toys that will stimulate their interest in different textures, sounds and colours**

### **I am...**

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

*Birth-36 months*



## **Pre-School**

**Interactive toys to develop their imagination and encourage language development**

### **I want...**

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

*3-6 years*



## **Electronic Learning Computers**

**Cool, aspirational and inspiring computers for curriculum related learning**

### **I need...**

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

*4-10 years*




To learn more about this and other VTech® products, visit [www.vtech.co.uk](http://www.vtech.co.uk)

# INTRODUCTION

Introducing the **Roar & Explore Wheel** by VTech®! start your engine for your next adventure with Lion and his koala friend! This brightly coloured and textured role-play steering wheel has a horn, light up indicators and a heart button that trigger fun phrases, sing-along songs and melodies.

On/Off/Volume Switch

Infant Car Seat/  
Pushchair  
Attachment Strap



# INCLUDED IN THIS PACKAGE

- Roar & Explore Wheel
- Parent's Guide


## WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

## NOTE

Please keep this Parent's Guide as it contains important information.

### Removing the Packaging Locks:



- ① Rotate the packaging locks anticlockwise 90 degrees.
- ② Pull out the packaging locks and discard.

# GETTING STARTED

## Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the steering wheel. Use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one side of each battery.
4. Install 2 new AAA batteries following the diagram inside the battery box.
5. Replace the battery cover and tighten the screw to secure.



## BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metal-hydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc), rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity (+ and -).
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

## Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

### **VTech® cares for the planet.**

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

#### **In the UK:**

Visit [www.recyclenow.com](http://www.recyclenow.com) to see a list of collection points near you.

#### **In Australia & New Zealand:**

Check with you local council for kerbside collections.

## WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.




## CAUTION:

Adult assembly required. For your child's safety, do not let them play with this toy until it is fully assembled.

# PRODUCT FEATURES



### 1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/Volume Switch** to the Low volume  or the High volume  position. You will hear a song, a phrase and a short tune. To turn the unit **Off**, slide the **On/Off/Volume Switch** to the Off  position.



### 2. Infant Car Seat/ Pushchair Attachment

The **Roar & Explore Wheel** can be attached to a car seat or pushchair bar. To do so, wrap the elastic loop around the bar and secure the hook and loop closure on the strap.



### 3. Automatic Shut-Off

To preserve battery life, the **Roar & Explore Wheel** will automatically shut off after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

## NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

## ACTIVITIES

### 1. Lion Button

Press the interactive **Lion Button** to hear fun songs, phrases, sounds and music. The lights will flash with the sound.




### 2. Light Up Indicator Buttons

Press the **Light Up Indicator Buttons** to hear playful sounds. The lights will flash with the sound.



### 3. Car Button

Press the **Car Button** to hear car engine sounds and playful phrases. The lights will flash with the sound.



#### 4. **Steering Wheel**

Turn the **Steering Wheel** to trigger the motion sensor and hear an assortment of fun sounds and music. The light will flash with the sound.



## MELODY LIST

1. Aiken Drum
2. For He's a Jolly Good Fellow
3. Hey Diddle Diddle
4. Bicycle Built for Two
5. A-Tisket, A-Tasket
6. Yankee Doodle
7. Three Little Kittens
8. Take Me Out to the Ball Game
9. London Bridge
10. Pat-a-Cake

## SONG LYRICS

### **Song 1**

Vroom, Vroom! Twist and spin!  
Vroom, Vroom! Turn and shake!  
Vroom, Vroom! Woo hoo!  
Let's go on an adventure!

### **Song 2**

Roar, roar,  
Let's go for a drive,  
Beep, beep, beep,  
Wave and say hello!

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

## TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you

# CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## **UK Customers:**

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: [www.vtech.co.uk/support](http://www.vtech.co.uk/support)

## **Australian Customers:**

Phone: 1800 862 155

Website: [support.vtech.com.au](http://support.vtech.com.au)

## **NZ Customers:**

Phone: 0800 400 785

Website: [support.vtech.com.au](http://support.vtech.com.au)

# PRODUCT WARRANTY/ CONSUMER GUARANTEES

## **UK Customers:**

Read our complete warranty policy online at [vtech.co.uk/warranty](http://vtech.co.uk/warranty).

## **Australian Customers:**

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –  
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to [vtech.com.au/consumerguarantees](http://vtech.com.au/consumerguarantees) for further information.

**Visit our website for more  
information about our products,  
downloads, resources and more.**

***www.vtech.co.uk***  
***www.vtech.com.au***



TM & © 2020 VTech Holdings Limited.  
All rights reserved.  
**Printed in China.**  
91-003927-001 