

vtech®

Instruction Manual

Toot-Toot Drivers®

Police Station



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk


INTRODUCTION

Thank you for purchasing the **VTech® Toot-Toot Drivers® Police Station**.

Little ones will love exploring this cool Police Station. Race to the emergency with the SmartPoint™ police car, helicopter and getaway car. It's time to get moving!



INCLUDED IN THE PACKAGE



One **SmartPoint™**
Police Car



Mini Getaway Car




Mini Helicopter



One **SmartPoint™**
Platform



One Jail Gate 1




One Jail Gate 2



One Jail Gate 3




One Lift Roof



Three White Pillars



SmartPoint™
Lift & Launcher



One **SmartPoint™**
Parking Area



One Helipad Big
Support




Two Helipad
Pillars



One Helipad



One Car Park Gate



Two Blue Pillars



One Slide Track



One Traffic Light



One Slide Support



One Flip-Up Gate



One Second
Floor Base

- Sticker Sheet
- Quick Start Guide

WARNING


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

Removing the Packaging Locks:

- ① Turn the packaging locks anticlockwise several times.
- ② Pull out the packaging locks and discard.



GETTING STARTED


WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.

Battery Removal And Installation

1. Make sure the unit is turned **OFF**.
2. Find the battery cover located on the bottom of the Police Car, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For



best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).

5. Replace the battery cover and tighten the screw to secure.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:


www.vtech.co.uk/recycle






www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

LABEL APPLICATION

Please stick the labels to the play set as shown below:






ASSEMBLY INSTRUCTIONS

With the **Toot-Toot Drivers® Police Station**, safety comes first.
To ensure your child's safety, adult assembly is required.


Assemble and attach the SmartPoint™ Parking Area and SmartPoint™ Lift & Launcher and Three White Pillars(A,B,C)

1. Following the steps as below:

A. Insert the SmartPoint™ Lift & Launcher into the SmartPoint™ Parking Area. Then straighten up the SmartPoint™ before inserting the Three White Pillars into the slots. Make sure you hear a clicking sound to confirm they are firmly connected.




B. Insert the Two Blue Pillars and the Car Park Gate into the slots. Make sure you hear a clicking sound to confirm they are firmly connected.



2. Assemble and attach the Lift Roof and Second Floor Base following the steps as below:

Attach the Lift Roof to the Second Floor Base with Pillars, then, insert the connected Lift Roof and the Second Floor Base into the pillars.




3. Assemble and attach the Two Helipad Pillars and the Helipad Big Support following the steps as below:

A. Insert Two Helipad Pillars into the Second Floor Base.




B. Insert the Helipad Big Support into the Second Floor Base interfaces. Insert the Helipad on the top.




4. Assemble and attach the Slide Track, Flip-Up Gate and Traffic Light following the steps below:

A. Insert the Slide Support into the Slide Track. Connect the Slide Track to the Second Floor Base.






B. Insert the Flip-Up Gate and Traffic Light onto the Slide Track



5. Assemble and attach the Jail Gate 1&2&3 and SmartPoint™ platform following the steps as below:

A. Connect Jail Gate 1 and 2, then connect Jail Gate 2 and 3. Put the SmartPoint™ platform onto the Jail Gate. Connect the completed Gate to the SmartPoint™ Parking Area.






Once you've completed the above steps, you are ready to play! You can connect the Police Station to other **Toot-Toot Drivers®** play sets and tracks (each sold separately).



PRODUCT FEATURES

1. On/Off Switch

To turn the unit **On**, slide the **On/Off Switch** to the **On** () position. To turn the unit **Off**, slide the **On/Off Switch** to the **Off** () position.



2. Automatic Shut-Off

To preserve battery life, the **Toot-Toot Drivers® Police Car** will automatically power down after approximately 60 seconds without input. The unit can be turned on again by pressing the light up face button, opening the bonnet, rolling the car quickly or triggering a **SmartPoint™** location.

Note: This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit repeatedly powers down while playing, please install a new set of batteries.

ACTIVITIES

Police Car

1. Press the **Light Up Face Button** to hear fun phrases, songs, sounds and melodies. While a melody is playing, continue pushing the **Police Car** to add in fun sounds on top of the melody. The Light Up Face Button will flash with sounds.
2. Push the **Police Car** to hear fun sounds and phrases. The Light Up Face Button will flash with sounds.
3. Open and Close the **Bonnet** to hear fun sounds and phrases. The Light Up Face Button will flash with sounds.
4. Place the **Police Car** on one of the play set's three **SmartPoint™** locations to see the **Police Car's** lights flash and to hear fun sounds, short tunes and phrases. The **Police Car** even interacts with other **Toot-Toot Drivers®** play sets (other play sets sold separately).



ACTIVITIES

Police Station

1. Place the **Police Car** or any **SmartPoint™** vehicle (each sold separately) on any of the 3 **SmartPoint™** locations to trigger fun sounds, songs or phrases.
2. Put the **Police Car** on the **SmartPoint™** Lift & Launcher, then lift the launcher to send the Police Car racing.
3. Move the Flip-Up Gate to let the **Police Car** slide out when the Traffic Light is green.
4. Put the **Police Car** on the **SmartPoint™** Car Parking to have a rest.



5. Put the **Police Car** on the **SmartPoint™ Jail Launcher** and then launch the vehicle.



MELODY LIST

1. Jack Be Nimble
2. London Bridge
3. My Bonnie Lies Over the Ocean
4. Old King Cole
5. Red River Valley
6. Take Me Out to the Ball Game

SONG LIST

Song 1

I'm a police car who loves to help.
I'll rush to the scene when I'm called.

Song 2

My bright flashing lights.
Mean I'm here to help everyone, everyday.

Song 3

Toot-Toot Drivers.
I'm a Toot-Toot Drivers Police Car.
Call, and I'll come quick to help (Toot-Toot).
I'll always be there for you!
Let's Toot-Toot and see (Toot-Toot).

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the unit still does not work, install a new set of batteries.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

