



My 1st Doll - Mia



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

ehoo

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

vtech Bally

lam...

and effect

toddle

Toys that will stimulate their interest in different textures. sounds and colours

...responding to colours,

sounds and textures

...understanding cause

...learning to touch, reach,

grasp, sit-up, crawl and

want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity so my whole brain

with drawing and music develops

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years

Birth-36 months



INTRODUCTION

Thank you for purchasing **My 1st Doll - Mia** by **VTech**®! This soft little baby doll is the perfect playtime and sleepy time companion. Featuring Day and Night modes which offer a variety of loving phrases, sounds, songs and melodies.



INCLUDED IN THIS PACKAGE

- · One My 1st Doll Mia
- One Parent's Guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy and should be discarded for your child's safety.

NOTE:

Please keep this Parent's Guide as it contains important information.

GETTING STARTED

The **My 1st Doll - Mia** is in try-me mode in the packaging. To exit try-me mode, just slide the Off/Day/Night Switch from Day/Night to Off to Day/Night. Normal play mode will then proceed.

BATTERY REMOVAL AND INSTALLATION

- 1. Open the fabric on the back of the doll.
- 2. Make sure the unit is turned OFF.
- Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw. Then, remove the cover.
- If a used battery is present, remove it from the unit by pulling up on one end of the battery.
- Install 1 new AA (LR6/AM-3)
 battery following the diagram
 inside the battery box. (For
 best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
- 6. Replace the battery cover and tighten the screw to secure.

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- · Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:

Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with you local council for kerbside collections.

Product Features

1. Off/ Day/ Night Switch

Slide the Off/ Day/ Night Switch to the Day/ Night position to turn the unit ON and enter Day or Night mode. Slide the switch to Off to turn the unit off



2. Music and Sound Buttons

Press the **Music Button** and **Sound Button** to hear sing-along songs, fun
sounds and phrases in **Day** mode. In **Night**mode, press these buttons to hear soothing



lullabies and nature sounds. The lullabies and soothing sounds will play for around 15 minutes. To add soothing sounds over the top off the lullabies, press the **Sound Button**. If you press the **Sound Button** again it will stop the lullabies from playing. Pressing the **Music Button** will also stop the soothing sounds.

3. Light Up Turtle

The **Light Up Turtle** will flash in **Day** mode along with the singalong songs, sounds and phrases. In **Night** mode the light will slowly fade in and out.

4. Automatic Shut-Off

To preserve battery life, **My 1st Doll - Mia** will automatically power down after several seconds without input in **Day** mode. In **Night** mode, **My 1st Doll - Mia** will automatically power down after approximately 15 minutes. The unit can be turned on again by pressing any button.

Note:

If the unit repeatedly powers down while playing, please insert new batteries and try switching it on again.

SING-ALONG SONG LYRICS

SONG 1

We can play all day long,

We can have lots of fun!

Clap and sing along,

because we are having lots of fun!

SONG 2

- 1, 2, 3, count with me,
- 3, 2, 1, dance along!
- 1, 2, 3, yippee!

SONG 3

Let's go on an adventure,

just you and me!

We can play together,

So happily!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit is not in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- Turn the unit ON. The unit should now be ready to play with again.
- If the product still does not work, please install a brand new set of batteries.

If the problem persists, please contact our Consumer Services
Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au

