

Instruction Manual

Sunshine Days Tummy Time Piano



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

School

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years

vtech Bally

Toys that will stimulate their interest in different textures. sounds and colours

lam...

- ...responding to colours, sounds and textures
- ...understanding cause and effect
- ...learning to touch, reach, grasp, sit-up, crawl and toddle

l want

- ...to get ready for school by starting to learn the alphabet and counting
- ...my learning to be as fun, easy and exciting as can be
- ...to show my creativity with drawing and music so my whole brain develops

Birth-36 months



To Jearn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Introducing the **Sunshine Days Tummy Time Piano** by **VTech®!** Meet the four animal characters by pressing the soft fabric keys, triggering fun sounds and melodies. Turn the page to hear sing-along songs and melodies!



Four Piano Keys

INCLUDED IN THE PACKAGE

- Sunshine Days Tummy Time Piano
- Quick Start Guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

 $\label{thm:please} \mbox{Please save this Instruction Manual as it contains important information.}$

Unlock the packaging locks:




- 1 Rotate the packing locks 90 degrees anticlockwise
- 2 Pull out the packing locks

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Locate the battery cover on the back of the electronic module. Use a screwdriver to loosen the screw and then open up the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- 4. Install 2 new AAA batteries following the diagram inside the battery box.
- 5. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

VTech® cares for the planet.

Care for the environment and give your toy a second life by disposing of it at a small electricals collection point so all its materials can be recycled.

In the UK:


Visit www.recyclenow.com to see a list of collection points near you.

In Australia & New Zealand:

Check with your local council for kerbside collections.

PRODUCT FEATURES

1. On/Low/High Volume Switch
To turn the Piano ON, slide the On/
Low/High Volume Switch to the
Low Volume (◄)) or High Volume
(◄)) position. To turn the Piano OFF,
slide the On/Low/High Volume
Switch to the OFF (●) position.



2. Automatic Shut-Off

To preserve battery life, the **Piano** will automatically power-down after approximately 60 seconds without input. The **Piano** can be turned on again by pressing any button.

NOTE

If the unit powers down or the light fades out during play, we suggest installing a brand new set of batteries.


ACTIVITIES

1. Piano Keys

Press the **Piano Keys** to learn about colours, animals and hear fun melodies. The light pattern will flash with the sounds.

2. Turnable Page

Turn the page to hear playful songs and soothing melodies. The light pattern will flash with the sounds.





MELODY LIST

- 1. Aiken Drum
- 2. Allen Chop Waltz
- 3. Alphabet Song
- 4. Bingo
- 5. Entertainer
- 6. Girls and Boys Come Out to Play
- 7. Hey Diddle Diddle
- 8. Hot Cross Buns
- 9. Humpty Dumpty
- 10. Looby Loo
- 11. Mary Had a Little Lamb
- 12. Old MacDonald
- 13. On Top of Old Smokey
- 14. One Man Went to Mow a Meadow
- 15. Pat-A-Cake
- 16. Pease Porridge Hot
- 17. Row, Row, Row Your Boat

- 18. Sailing, Sailing
- 19. Skip to My Lou
- 20. Teddy Bears' Picnic
- 21. A-Tisket, A-Tasket

SING-ALONG SONG LYRICS

Song 1

Tap-tap the keys, Tap the keys, play a song. Tap-tap-tap the keys, Tap the keys and sing along.

SONG 2

A-tisket, A-tasket, A green and yellow basket, I wrote a letter to my love, On the way I dropped it.

SONG 3

If you go down to the woods today, You're sure of a big surprise. If you go down to the woods today, You'd better go in disguise.

SONG 4

Tip-toe, tip-toe, caterpillar tip-toes across the ground.

SONG 5

What a giggly and happy little bear!

SONG 6

Fox likes to play with his forest friends.

SONG 7

Hoot-hoot, owl hoots and stays up all night. Hoot!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat sources.
- Remove the batteries if the unit will not be in use for an extended period of time.
- Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit sit for a few minutes, then replace the batteries.
- Turn the unit ON. The unit should now be ready to play with again.
- If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing VTech® products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty. Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

Visit our website for more information about our products, downloads, resources and more.

www.vtech.co.uk www.vtech.com.au

