

Parent's Guide



Garage



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

School

Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

Ineed

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

National Curriculum based content to support what I'm learning at school

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

lam...

vtech Bally

Toys that will

...responding to colours, sounds and textures

stimulate their interest

in different textures. sounds and colours

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months






INTRODUCTION

Thank you for purchasing the VTech® Toot-Toot Drivers® Garage!

Park, learn and play with the **Toot-Toot Drivers® Garage!** This interactive garage features two floors of pretend play and learning fun! Place the Tow Truck on the lift and watch it spin when raised up to the first level platform. Then, push the tow truck to watch it race under the helipad, down the spiral ramp and arrive at the car wash platform!



INCLUDED IN THIS PACKAGE

NOTE: This toy is not intended for teething.



One **SmartPoint**™ Tow Truck



One base



One first level platform



One lift gate



One lift support



One centre support



One pillar support



One lift wall



One lift platform



One lift bracket



One car wash platform



One car wash brush



One car wash gate



One helipad platform



Two helipad supports



One repair platform



One ramp track support



Ramp track A



Ramp track B



Two gears



One ticket booth



One first level sign



One gate arm



One gate base



One platform track



One label sheet

- One parent's guide

WARNING:


All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE: Please keep user's manual as it contains important information.

Adult assembly required.

Unlock the packaging locks:

- Turn the packaging lock anticlockwise several times.
- 2 Pull out and discard the packaging lock.



GETTING STARTED

BATTERY INSTALLATION

Tow Truck

- 1. Make sure the unit is turned OFF.
- 2. Locate the battery cover on the bottom of the Tow Truck. Use a screwdriver to loosen the screw.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY INSTALLATION - Garage

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the bottom of the Garage. Use a screwdriver to loosen the screw.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries or fully charged NI-MH (Nickel Metalhydride) rechargeable batteries for best performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable, or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- · Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- · Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.


Help protect the environment by disposing of your product or batteries responsibly.


For more information, please visit:


www.recycle-more.co.uk www.recyclenow.com

LABEL APPLICATION

Please stick the labels to the play set securely as indicated on the following pages:







ASSEMBLY INSTRUCTIONS Garage

With the **VTech® Toot-Toot Drivers® Garage**, safety comes first. To ensure your child's safety, adult assembly is required.

 With the Base right-side up, insert the Centre Support, Pillar Support, Lift Support and Lift Gate into the slots on the Base, as shown below. You will hear a "click" sound to indicate the pieces are secure.







With the First Level Platform right-side up, attach it to the three connected supports, as shown below. You will hear a "click" sound to indicate the pieces are secure.




- Next, assemble and attach the lift components following the steps below:
 - A. Slide the Lift Platform into the slot on the Lift Wall, as shown below. Lift the handle and press down on the Lift Platform to lower it.



B. Then, attach the Lift Wall to the Base and First Level Platform, as shown below. You will hear a "click" sound to indicate the Lift Wall is secure.




C. Connect the Lift Bracket to the Lift Wall and Lift Gate, as shown below. Pull down on the Lift Bracket to make sure it is secure.



- Assemble and attach the Car Wash, Spiral Ramp and Repair Platform following the steps below:
 - A. Attach the Car Wash Brush to the Car Wash Gate, as shown below. Once the pieces are attached, connect the Car Wash Gate to the Car Wash Platform, as shown below.







Note: Once the Car Wash Gate is attached, it cannot be removed.


B. Attach Ramp Track A to the Ramp Track Support. Then, attach the Repair Platform to the Ramp Track Support and Ramp Track A, as shown below. You will hear a "click" sound to indicate the pieces are secure.






C. Attach Ramp Track B to Ramp Track A. Then, attach the Car Wash to Ramp Track A and Ramp Track B, as shown below.






D. Lastly, attach Ramp Track A to the First Level Platform. Then, attach the Car Wash Platform and Ramp Track B to the Base, as shown below.




 Insert the Helipad Supports into the bottom of the Helipad Platform, and then attach to the First Level Platform, as shown below.






 Insert the Ticket Booth, First Level Sign and Gears into the First Level Platform, as shown below. You will hear a "click" sound to indicate the pieces are secure.





 Insert the Gate Arm through the bottom of the Gate Base. Then, attach the Gate to the Base, and the Platform Track to the Ramp Track Support, as shown below.





Once you've completed the above steps, you are ready to play! You can connect the play set to other **Toot-Toot Drivers**® play sets (each sold separately).



EXPAND & EXPLORE

Connect to the **Toot-Toot Drivers® Deluxe Track Set** (as shown below) or other **Toot-Toot Drivers®** play sets (each sold separately) to expand the **Garage** and inspire creativity.




PRODUCT FEATURES

Tow Truck

1. ON/OFF SWITCH

To turn the Tow Truck **ON**, slide the **ON/OFF SWITCH** on the Tow Truck to the **ON** (**①**) position. To turn the Tow Truck **OFF**, slide the **ON/OFF SWITCH** to the **OFF** (**●**) position.



2. AUTOMATIC SHUT-OFF


To preserve battery life, the included Tow Truck will automatically power-down after approximately 60 seconds without input. The unit can only be turned on again by pressing the **Light Up Button**, pushing the Tow Truck quickly or triggering a **SmartPoint**™ location.

NOTE: This product is in Try-Me mode in the packaging. After opening the package, turn the vehicle off and on again to proceed with normal play. If the unit powers down while playing, we suggest changing the batteries.

ACTIVITIES

Tow Truck


 Slide the On/Off Switch to turn the Tow Truck ON. You will hear a song, fun phrases and sounds. The light will flash with the sounds.



Press the Light Up Button to hear fun sounds, songs and phrases. The light will flash with the sounds.



 Push the Tow Truck to hear fun sounds and melodies. While a melody is playing, continue pushing the Tow Truck to add in fun sounds on the top of the melody. The light will flash with the sounds.




4. For added fun, the Tow Truck interacts with the Toot-Toot Drivers® Garage . Simply put the Tow Truck on one of the play set's nine SmartPoint™ locations to see the Tow Truck's light flash and to hear fun sounds, short tunes and phrases. The Tow Truck even interacts with other Toot-Toot Drivers® play sets (each play set sold separately).

PRODUCT FEATURES - GARAGE

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the On/Off/Volume Control Switch to the low volume (\P) or high volume (\P) position. To turn the unit OFF, slide the On/Off/Volume Control Switch to the OFF (\P) position.



2. SMARTPOINT LOCATIONS

The Garage includes 9 **SmartPoint**[™] locations that interact with the included Tow Truck or any other **Toot-Toot Drivers**® **SmartPoint**[™] vehicles (each sold separately). Simply roll or place the vehicle over a SmartPoint[™] location to hear fun sounds, phrases and music.


3. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Toot-Toot Drivers® Garage will automatically power-down after approximately 60 seconds without input. To wake up the unit, activate any of the electronic features on the play set.

ACTIVITIES

Garage

 Slide the On/Off/Volume Control Switch to either volume setting to turn the unit on. You will hear a song, phrase and fun sound. The lights will flash with the sounds.



Press the Light Up Buttons to hear fun phrases, sounds, songs and melodies. The lights will flash with sounds.



 Place the Tow Truck or any SmartPoint™ vehicle (each sold separately) on any of the play set's nine SmartPoint™ locations to trigger fun sounds, songs or phrases.



 Place the Tow Truck on the lift and raise the lift to the ground floor. Once the lift reaches the top, the Tow Truck will slide out of the lift to the first floor.



- Roll the Tow Truck down the spiral ramp and the vehicle will stop at the car wash. Spin the brush to pretend to wash the vehicle and press the tyre to release the vehicle.
- Move the spanner back and forth on the repair platform to pretend to fix the vehicle.





SING-ALONG SONGS

Tow Truck

SONG 1

My friend needs my help on the road, Here I, here I go!

SONG 2

Do you need a tow? Where'd you like to go? I'll keep you safe and sound!

SONG 3

If your car breaks down, I will tow it back to town.

Garage

SONG 1

Come and take the lift. Go up, go down. Check your car, wash it clean, There's lots of things to do.

SONG 2

No matter how big or small, Repair it, fuel up, You will be ready to go.

SONG 3

Welcome to the garage. Park up, Zoom about, Wave goodbye as you leave!

MELODY LIST

Tow Truck

- 1. Mexican Hat Dance
- 2. Oh, Dear! What Can the Matter Be?
- 3. Oranges and Lemons
- 4. The Red River Valley
- 5. Sing a Song of Sixpence
- 6. Ta-ra-ra Boom-de-ay

Garage

- 1. Bingo
- 2. The Farmer in the Dell
- 3. London Bridge
- 4. Jack & Jill
- 5. Oh Susannah
- 6. Pat a Cake
- 7. Turkey in the Straw
- 8. Bill Bailey
- 9. Animal Fair
- 10. Incy Wincy Spider
- Mulberry Bush
- 12. Old King Cole
- 13. Hey Diddle Diddle
- 14. Camptown Races
- 15. Polly Wolly Doddle

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit sit for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 0330 678 0149 (from UK) or + 44 330 678 0149 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 0330 678 0149 (from UK) or + 44 330 678 0149 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.



PRODUCT REGISTRATION

Visit www.vtech.co.uk/clubvtech/login to register your VTech product

By joining the VTech Club you can also enter competitions, find out about news and events, seek expert advice for parents and let your kids play fun learning games and activities



PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- 3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- 7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- 8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor). Please include details of the fault together with your name and address.
- To keep an online record of your warranty, please register your product online at www. vtech.co.uk/warranty

Vtech Electronics EU PLC, c/o XPO Logistics, Warehouse 350, Cat & Fiddle Lane, West Hallam, DE7 6HE

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.



Visit our website for more information about our products, downloads, resources and more.

vtech.co.uk

