


vtech[®]
baby

Instruction Manual

Little Friendlies Musical Soft Ball



© 2015 VTech
Printed in China
91-002989-021 

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® Little Friendlies Musical Soft Ball** learning toy!

It's a circus of fun with the **Little Friendlies Musical Soft Ball!**

Press the big music button to learn about the colourful animals. Then throw, shake, bounce and roll the bright ball to hear cheerful music and more!



INCLUDED IN THIS PACKAGE

- One VTech® Little Friendlies Musical Soft Ball
- One Instruction Manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this Instruction Manual as it contains important information.

WARNING:

Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.

GETTING STARTED

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product




The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle

www.vtech.com.au/sustainability.

* Visit www.recyclenow.com to see a list of collection points near you.

ASSEMBLY INSTRUCTIONS


To ensure your child's safety, this product should only be assembled by an adult.

REMOVABLE ELECTRONIC MUSIC BOX

1. To remove the electronic music box, open the hook and eye and the covering cotton on the bottom of the ball. Pull the electronic box out.




2. To insert the electronic music box, push the box into the ball ensuring the round end goes in first. See the image on the covering cotton for reference. You'll hear a click when inserted correctly. Close the covering cotton and seal the hook and eye.



PRODUCT FEATURES

1. ON/OFF VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **On/Off Volume Control Switch** on the electronic box to the **Low Volume** (🔊) or **High Volume** (🔊) position. To turn the unit **OFF**, slide the **On/Off Volume Control Switch** to the **OFF** (●) position.




2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Little Friendlies Musical Soft Ball** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing the music button.

ACTIVITIES

1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a song, a fun phrase and a playful sound.
2. Press the **music button** to learn about animals and numbers as well as a variety of playful sounds and melodies.



3. Roll, throw or push the ball to activate the motion sensor and hear a variety of playful sounds and songs.



MELODY LIST

1. Take Me Out to the Ball Game
2. Bicycle Built For Two
3. Boys and Girls Come Out to Play
4. Camptown Races
5. I've Been Working on the Railroad
6. This Old Man
7. Little Boy Blue
8. The Animal Fair
9. Toyland
10. Skip to My Lou
11. Chopsticks
12. Polly Put the Kettle On
13. Humpty Dumpty
14. Aiken Drum
15. Ta-ra-ra Boom-de-ay

SING-ALONG SONG LYRICS

SONG 1

Grab your friends,
It's time to play!
Bounce, bounce, bounce the ball.

SONG 2

Throw the ball into the air,
Catch it, kick it, roll it, bowl it.
Playing with the ball is so much fun!

SONG 3

One, two, it's cool playing with you!

SONG 4

Three, four, roll the ball on the floor!

SONG 5

Five, six, let's bounce and roll!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. This toy works best indoors on smooth surfaces.
6. The fabric ball is machine washable. Please remove the electronic box and follow the care instructions on the label.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)
Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155
Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785
Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

