



Cora The Smart Cub®



© 2013 VTech Printed In China 91-002855-016 (JK) VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...



Interactive toys to develop their imagination and encourage language development

Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

vtech Bally

Toys that will stimulate their interest in different textures, sounds and colours

Lam...

- ...responding to colours, sounds and textures
- ...understanding cause and effect
- ...learning to touch, reach, grasp, sit-up, crawl and toddle

l want...

- ...to get ready for school by starting to learn the alphabet and counting
- ...my learning to be as fun, easy and exciting as can be
- ...to show my creativity with drawing and music so my whole brain develops

I need...

- ...challenging activities that can keep pace with my growing mind
- ...intelligent technology that adapts to my level of learning
- ...National Curriculum based content to support what I'm learning at school







To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION

Thank you for purchasing the VTech® Cora The Smart Cub® learning toy.

Cuddle and learn with **Cora The Smart Cub®** by **VTech®!** Cora and your child will grow together, learning greetings and body parts, reminding your child of special holidays and birthdays and play bedtime music to relax to. Personalise Cora through **VTech®** 's **Learning Lodge™** with your child's name, favourite stories and so much more. Your child's got a new best friend ... just ask, she knows your name!



INCLUDED IN THIS PACKAGE

- One VTech® Cora The Smart Cub®
- One USB cable
- One user's manual

WARNING: All packing materials, such as tape, plastic sheets,

wire ties and tags are not part of this toy, and should

be discarded for your child's safety.


NOTE: Please keep this instruction manual as it contains important

information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the electronic box inside the unit. Use a screwdriver to loosen the screw.
- Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbonzinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- · Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.
- If the batteries are removed from Cora for more than 30 seconds, you will have to reset Cora's internal clock by connecting it to the Learning Lodge™.

Disposal of batteries and product



The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk www.recyclenow.com

With the VTech® Cora The Smart Cub®, safety comes first. To ensure your child's safety, please ensure the battery cover is securely locked into position to avoid injury.


ATTENTION:

This product is in a try-me mode in the packaging. After opening the package, turn Cora off and on again to proceed with normal play.

PRODUCT FEATURES

1. OFF/VOLUME CONTROL SWITCH

Locate the electronic box inside your cub. To turn the unit **ON**, slide the **OFF/VOLUME CONTROL SWITCH** to the low volume (())) or high volume (())) position. To turn the unit **OFF**, slide the **OFF/VOLUME CONTROL SWITCH** to the **OFF** () position.



2. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Cora The Smart Cub® will automatically power-down after approximately 40 seconds without input. The unit can be turned on again by pressing any button.

PERSONALISING YOUR CUB

You can personalise **Cora The Smart Cub®** with your child's name, birthday, favourite things, special days, music and more by connecting to the **VTech® Learning Lodge™**.

SOFTWARE INSTALLATION

Before you can connect the VTech® Cora The Smart Cub® to your computer, you need to install the VTech® Cora The Smart Cub® software on your computer. To obtain the VTech® Cora The Smart Cub®, please go to the VTech® Cora The Smart Cub® download site on https://www.vtechuk.com/download and download the setup file.

Once the setup process is complete, connect the VTech® Cora The Smart Cub® to the computer using a USB cable. Locate the USB port inside your product, and plug the device into your computer's USB port.



The toy is only to be connected to Class II equipment bearing the following symbol \Box).

PERSONALISING CORA THE SMART CUB®

 About Me: Follow the instructions to personalise Cora with your child's name, birthday and favourite things.

Important: Please enter the time and date where you live to set Cora's internal clock.





- Special Days: Choose days that are special to your child and save them to Cora. Cora The Smart Cub® will reference these days as they approach when your child presses Cora's hand.
- Personal Messages: Choose up to 11 special messages for Cora to say to your child, such as morning, afternoon and bedtime greetings, as well as loving messages for any time of day. Hear timerelated messages by pressing Cora's tummy, and hear loving messages by pressing the heart button.
- Stories: Cora can be personalised with stories starring your child! Personal content chosen in the About Me section will be added to the short stories that you choose here. Hear the stories by pressing Cora's right hand.
- Music: Choose music to add to Cora. Select up to 8 playful sing-along songs, 15 playtime melodies and 15 bedtime melodies. Be sure to save the sing-along songs and playtime melodies first, then choose bedtime melodies and save again. Enjoy the downloaded music by pressing Cora's right foot and left foot.











- You can return to any screen at any time to make changes.
- To begin playing, disconnect Cora The Smart Cub® from your computer and remove the USB cable from Cora.

If Cora has been connected to the **Learning Lodge**™ for more than 15 minutes without input, Cora will play a reminder, then go into sleep mode. Disconnect Cora from your computer, then turn it off and back on again to resume play.

ACTIVITIES

1. ON/OFF BUTTON

Once the main power is on, press the **ON/OFF BUTTON** on Cora's ear to turn ON and OFF. You must press and hold this button for more than two seconds to turn off your cub.



2. SPECIAL DAYS & BIRTHDAY WISHES

Squeeze Cora's left hand to hear about celebrations. If you have downloaded Special Days content from the Learning Lodge™, you will hear phrases, songs and other music related to the special days you have downloaded.



3. HAND/STORIES

Squeeze Cora's right hand to learn about the hand. If you have downloaded story content from the Learning Lodge™, you will hear stories starring your child and your child's favourite things.



4. FOOT/PLAYTIME MUSIC

Squeeze Cora's left foot to learn about the foot. You will also hear playful songs and melodies. If you have downloaded additional sing-along songs and playtime melodies from the Learning Lodge™, you will hear them too.



5. BEDTIME MUSIC

Squeeze Cora's right foot button to hear bedtime melodies with three timer settings – 5 minutes, 15 minutes and 30 minutes. If you have downloaded additional bedtime music from the Learning Lodge™, you will hear them too.



6. HEART/LOVING MESSAGES

Press Cora's heart button to hear loving messages. If you have downloaded more loving messages from the Learning Lodge™, you will hear them too.



7. TUMMY/TIME-RELATED MESSAGES

Press Cora's tummy button to be asked to find body parts and to hear special messages relating to the time of day. If you have downloaded more time-related messages from the Learning Lodge $^{\text{TM}}$, you will hear them too.



8. MOTION SENSOR

Hug and tap the VTech® Cora The Smart Cub® to hear loving messages. If you have downloaded more loving messages from the Learning Lodge™, you will hear them, too.

PLAYTIME MELODIES LIST

- 1. A-Tisket, A-Tasket
- 2. Humpty Dumpty
- 3. Jack and Jill
- 4. London Bridge
- 5. Three Little Kittens
- 6. Old King Cole
- 7. Polly Wolly Doodle
- 8. Ring Around the Rosie
- 9. Teddy Bears' Picnic
- 10. Old MacDonald Had a Farm
- 11. The Bear Went over the Mountain
- 12. Did You Ever See a Lassie?
- 13. The Farmer in the Dell
- 14. The Glow Worm
- 15. I've Been Working on the Railroad

SING-ALONG SONG LYRICS

Sing-Along Song 1

Hello, my friend! Let's learn and play. We'll have fun, lots of fun, all day long!

Sing-Along Song 2

Touch my ears, Wiggle my toes, Tickle my tummy, Tap my nose!

Sing-Along Song 3

Pat my head, Rub my feet, Hold my hand, You're beary sweet!

Sing-Along Song 4

With my eyes, I can see, You're my friend, And you love me!

BEDTIME MUSIC LIST

- 1. Lullaby (Brahms)
- 2. Greensleeves (Traditional)
- 3. Canon in D (Pachelbel)
- 4. New World Symphony (Dvorak)
- 5. Serenade (Haydn)
- 6. Minuet in G (Bach)
- 7. Symphony No. 5 (Beethoven)
- 8. Ode to Joy (Beethoven)
- 9. Sleeping Beauty Waltz Op. 66 (Tchaikovsky)
- 10. Eine Kleine Nachtmusik (Mozart)
- 11. All Through the Night (Traditional)
- 12. Au Clair de la Lune (Traditional)
- 13. Moonlight Sonata (Traditional)
- 14. Rock-a-Bye, Baby (Traditional)
- 15. Air (Bach)

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit is not in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1 LED PRODUCT



vtech PRODUCT WARRANTY

Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.



- The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
- The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
- VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
- 4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
- 5. This warranty is personal to the original purchaser and is not transferable.
- 6. Breakages to the LCD screen are not covered by the warranty.
- Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
- Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).

Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.