

vtech[®]
Baby

User's Manual

Sleepytime Bear



© 2013 VTech
Printed in China
91-002833-002 

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours


I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION

Thank you for purchasing the **VTech® Sleepytime Bear!**

Sleepytime Bear is sure to help baby drift to sleep. This soft cuddly bear plays 32 soothing melodies along with 2 comforting sing-along songs. The bear has a soft glowing light-up tummy and has a volume control switch for quieter play. The electronics can be easily removed so the bear can be hand washed.



LIGHT-UP STAR
BUTTON

REMOVABLE
ELECTRONIC BOX



ON/OFF VOLUME
CONTROL SWITCH

INCLUDED IN THIS PACKAGE

- One VTech® Sleepytime Bear
- One user's manual

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


NOTE:

Please keep this user's manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the removable electronic box located inside the back of the bear. Use a screwdriver to loosen the screw.
3. Install 2 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.



Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com

ASSEMBLY INSTRUCTIONS

To ensure your child's safety, this product should only be assembled by an adult.

REMOVABLE ELECTRONIC BOX

1. To remove the electronic box, open the Velcro on the back of the bear. There is a button on the left side of the electronic box, press the button to detach and remove the electronic box.
2. To insert the electronic box, press same button you used to remove the electronic box and click it onto the tab inside the back of the bear. When the electronic box is inserted correctly you will hear a click sound. Push the electronic box into the back of the bear and seal the Velcro.



PRODUCT FEATURES

1. ON/OFF VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **On/Off Volume Control Switch** located on the removable electronic box inside the back of the bear to the **Low Volume** (🔊) or the **High Volume** (🔊) position. To turn the unit **OFF**, slide the **On/Off Volume Control Switch** to the **OFF** (●) position.



2. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Sleepytime Bear** will automatically power-down after the music has ended. The unit can be turned on again by pressing the light-up star button.

ACTIVITIES

1. Slide the **On/Off Volume Control Switch** to turn on the unit on. You will hear a song, phrase and a short tune. The light will fade in and out with the sounds.
2. Press the **light-up star button** to hear a variety of songs, phrases, nature sounds and melodies. You will hear approximately 10 minutes of music play after each press of the button. The light will fade in and out with the sounds.
3. Hold down the **light-up star button** to stop the current response.



MELODY LIST

1. Beautiful Dreamer
2. Clair de Lune (Debussy)
3. All Through The Night
4. Au Claire de la Lune
5. Moonlight Sonata (Beethoven)
6. Sleeping Beauty Waltz (Tchaikovsky)
7. To a Wild Rose (McDowell)
8. Canon in D (Pachelbel)
9. Lavender's Blue
10. Irish Lullaby
11. Spring Song
12. Fur Elise
13. Go Tell Aunt Rody
14. Cradle Song (Brahms)
15. The Riddle Song
16. Oh Dear! What Can the Matter Be?
17. Sweet and Low
18. Moonlight Bay
19. Dream of Love (Liszt)
20. Minuet in G (Bach)
21. Where Has My Little Dog Gone?
22. Morning - Peer Gynt Suite (Grieg)
23. Farmer in the Dell
24. Shenandoah
25. Rock-a-bye Baby
26. Greensleeves
27. Are You Sleeping?

28. Row, Row, Row Your Boat
29. Jesu, Joy of Man's Desiring (Bach)
30. Twinkle, Twinkle Little Star
31. Winter - The Four Seasons (Vivaldi)
32. Minuet (Mozart)

SING-ALONG SONGS

Sing-along song 1

Cuddle up with me at night,
In your arms you'll hold me tight.
My tummy's glowing oh so bright!

Sing-along song 2

Goodnight, sleep tight.
May sweet dreams fill your head!

CARE & MAINTENANCE

1. The bear is hand wash only. Remove the electronic box before washing.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CLASS 1
LED PRODUCT



PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

