

vtech[®]
baby

Instruction Manual

6-in-1 Playtime Tunnel



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **6-in-1 Playtime Tunnel!**

Introduce baby to a world of discovery for each stage of their growth. The interactive piano includes three play modes with three progressive levels that teach first words for animals, numbers and colours.



INCLUDED IN THE PACKAGE



Crawling Tunnel




Zebra Stand




Light Up Piano



6 Long Support Poles



3 Links




3 Support
Stand Pieces



Hippo Roller



Elephant Rattle



Koala Bead Ring




Soft Tiger




Crinkle Toucan



Sun Mirror



6 Activity Links



8 Screws

- Quick Start Guide


WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

Unlock the Packaging Locks



- ① Rotate the packaging locks anticlockwise 90 degrees.
- ② Pull out the packaging locks and discard.



CAUTION:

Adult assembly required. This package contains small parts. For your child's safety, do not let your child play with the toy until it is fully assembled.

GETTING STARTED


WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the piano, use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 3 new AA batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product




The crossed-out wheelee bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

 Please dispose of your product and batteries responsibly. In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled. Learn more at:

www.vtech.co.uk/recycle




www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.




ASSEMBLY INSTRUCTIONS

With the **6-in-1 Playtime Tunnel**, safety comes first. Adult assembly required. For your child's safety, do not let them play with this toy until it is fully assembled.


1. Attach the six **Long Support Poles (A)** to both ends of the three **Links (B)**. This will form three extended poles. Thread the three extended poles through the three openings at the beginning, middle and end of the **Crawling Tunnel** as indicated in the images to form three archways.




Tuck each pole end into the pocket at the end of each archway. Use a hard surface to push the pole further into the opening to make sure the pole end is covered by the pocket so the pole is not exposed. The poles are intended to fit snugly to create a sturdy crawling tunnel.




2. Connect the three **Support Stand Pieces** with the eight **Screws**.




3. Attach the **Crawling Tunnel** to the **Support Stand** by inserting the attachment tabs on the **Play Mat** through the slots on the base of the **Support Stand**.



4. Attach the **Zebra Stand** to the left side of the **Support Stand** as shown. You will hear the **Zebra Stand** click into place when connected properly.




5. Attach the ends of the arch to the base of the **Support Stand** and to the top of the **Zebra Stand**. You will hear the arch click into place when connected properly.




6. Attach the **Zebra Stand** to the tunnel. Hook the two fabric loops on the left side of the **Crawling Tunnel** to the tabs on the zebra's back.



7. Attach the sensory toys to the activity links, then attach the links to the fabric loops on the arches.



8. Attach the **Light Up Piano** to the zebra stand. You will hear the piano click into place when connected properly.
9. To remove the **Light Up Piano**, press the grey release tab on the zebra.



PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/Volume Switch** to the Low volume (🔊) or the High volume (🔊🔊) position. You will hear a phrase, a song and a short tune. To turn the unit **Off**, slide the **On/Off/Volume Switch** to the **Off** (●) position.



2. Mode Switch

Slide the **Mode Switch** to the Music mode (🎵), Animal mode (🐾) or Explore mode (🔍) position.



3. Automatic Shut-Off

To preserve battery life, the **6-in-1 Playtime Tunnel** will automatically shut off after approximately 40 seconds without input. The unit can be turned on again by pressing any button.

NOTE

If the unit powers down or the light fades out during play, please install a new set of batteries.

ACTIVITIES

Light Up Piano Buttons

Press the **Piano Buttons** to hear fun sounds and melodies in Music mode, learn about animals and their sounds in Animal mode, and learn about numbers, counting and colours in Explore mode. The lights will flash with the sounds.



MELODIES

1. Yankee Doodle
2. Good Morning, Merry Sunshine
3. Rockin' Robin
4. Aiken Drum
5. A-Tisket, A-Tasket
6. Skip to My Lou
7. Toyland
8. Teddy Bears' Picnic
9. Polly Put the Kettle On
10. On Top of Old Smokey
11. Here We Go 'Round the Mulberry Bush
12. MacNamara's Band

SONG LYRICS

Song 1

Would you like to make a song?
It'll be do-re-mi-fa-so good!

Song 2

Hey there friend, it's time to play,
Our animal friends are here, hooray!
They run, they roar, they sing, and more.
We'll have so much fun together!

Song 3

One, two, three, four, fun animals,
Love to count and learn with you!
Green, orange, yellow and also blue,
Explore the colours of the rainbow.

Song 4

Elephant has two big ears,
Elephant has two big ears,
Elephant has two big ears,
And a long, long trunk!

Song 5

Sloth is brown and furry.
Sloth likes hanging in the trees.
Sloth is slow but not lazy.
Sloth is small and happy.

Song 6

Who's that with orange fur?
Who's that with brown stripes?
Who's that with the mighty roar?
It's our friend, tiger!

Song 7

Zebra lives in the Serengeti,
Covered in black and white stripes and very mighty!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. The crawling tunnel, soft tiger and crinkle toucan are surface washable only.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services Department, and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

**VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES**

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

